





Assembly & Instruction Manual

SKU:800-200

Walk-in greenhouse Installation Guide



VERSION:20230313

Save this manual for future reference

Assembly Instructions

Part List

No.		Qty
HJ58-992L		2
HJ58-992R		2
HJ43-1498		2
HJ43-1477		2
HJ43-1773		2








No.		Qty
HJ51-1674L		1
HJ51-1674R		1
HJ55-468		1
HJ52-509		2
HJ50-1408-1		2
HJ50-1408-2		2
HJ57-1405		8
HJ46-1477		2
HJ46-1500		2
HJ49-1500		1
HJ49-1477		1
HJ53-1786L		1
HJ53-1786R		1
HJ54-1786L		1
HJ54-1786R		1





No.		Qty
HJ47-1487		2
HJ47-1511		2
HJ56-1002L		2
HJ56-1002R		2
HJ57-1002		4
HJ56-573M		4
HJ56-573L		2
HJ56-573R		2
HJ40-624		2
HJ42-624		2
HJ41-492		4





No.		Qty	No.		Qty
40		M4.2x15 24	48		M6x12 71
41		M6x35 12	49		M4x60 1
42		M6x12 36	50		M4 1
43		M6x20 2	51		6x12 1
44		M4x12 6	52		6x30 4
45		M6 92			
46		M6x16 4			
47		M6x30 4			











Assembly Instructions

Part List





No.		Qty
SP1		15
SP2		8
SP3		2
SP4		2
SP5		1
SP6		4
SP7		1
SP8		2

MA		1
MB		1
MC		1
MD		1



No.		Qty
JA		2
JB		2
JC		4
JD		2

34		2
33A		2
33B		2
36A		2
36B		2
32		4
35A		4
26		4
31B		2
FP2		4



Assembly Instructions





Assembly Instructions



Assembly



Assembly



Assembly

HJ53-1786L



45



..... 2


HJ53-1786R




48




..... 2





SP1



..... 5



Assembly



Assembly

48






.....4

45



.....4



HJ56-573M




.....1


48





.....2





HJ56-573M



Assembly






Assembly



Assembly



45

⊗4



42

⊗4



Assembly

HJ46-1477



..... 2

45



..... 4

HJ46-1500




..... 2

47




..... 4




x2


42





..... 4





42



Assembly



Assembly



Assembly

HJ57-1002






..... 4

48






.....12





45



.....8



Assembly



Assembly

HJ56-1002L



.....2

45



.....8


HJ56-1002R




.....2

HJ56-1002R

HJ56-1002L



HJ56-1002R



HJ56-1002L

Assembly

HJ56-573M






.....2

48



.....6

x2





45



.....4


HJ56-573M





45

Assembly


SP1



.....10




SP3





.....2



SP2





.....8












Assembly







Assembly










Assembly

- | | | | | | | | | |
|-----------|---|--------|-----------|---|--------|-----------|---|--------|
| MA |  |1 | MD |  |1 | 50 |  |1 |
| MB |  |1 | 49 |  |1 | 42 |  |1 |
| MC |  |1 | 45 |  |1 | 51 |  |1 |





- | | | | | | |
|------------|---|--------|-----------------|--|--------|
| SP4 |  |1 | HJ52-509 |  |1 |
|------------|---|--------|-----------------|--|--------|

- | | | |
|------------|---|--------|
| 40 |  |2 |
| 42 |  |2 |
| 36A |  |1 |
| 36B |  |1 |



Assembly




44 6





HJ42-624 2

48 2

x2



Assembly



Assembly

HJ40-624





.....2




40



.....4



x2




Assembly


JA 2

JC 4


JB 2

x2





JA 2

43 2



JB 2

45 6

JD 2



Assembly



Assembly

42




.....8


HJ47-1487

HJ47-1511

HJ47-1487



42



35A




.....4

40





.....8



40

35A

Assembly



Please don't hesitate to contact us for any further questions,
your satisfaction is guaranteed.
customerservice@aoodor.com
<https://www.aoodor.com/>