


Assembly Instructions



ASSEMBLY RATING

The Assembly Rating is a 5-point system that shows the degree of effort needed in assembling a specific product (with 1 being easy and 5 being difficult). For some products, two persons are recommended.


EASY



DIFFICULT

Tools Required For Assembly:

Allen Wrench



(Included)




2 PERSONS RECOMMENDED


ASSEMBLY & CARE ADVICE

FOR YOUR FURNITURE TO LAST, CORRECT ASSEMBLY AND PROPER MAINTENANCE ARE NECESSARY. PLEASE FOLLOW THE INFORMATION PROVIDED BELOW TO FULLY ENJOY YOUR FURNITURE.


BASIC ASSEMBLY TECHNIQUES




When lock or spring washer is used in an assembly, please make sure the lock or spring washer is placed between the larger flat washer and the head of the screw or bolt.




Position each part correctly and insert screws or bolts into their respective holes by hand tighten or using the proper hand tool. Only tighten when step is completed or when instructed to do so.



Use cardboard or carpet area when assembling furniture to prevent scratches. Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.



Some furniture comes with height adjustment knobs underneath each leg. To lower or to raise each leg, you need to turn clockwise or counterclockwise, respectively.



Make sure all parts are properly aligned, then use the appropriate hand tool to completely tighten the bolts or screws. Do not use power tools and do not overtighten.




Save the Instructions and store the Allen wrench or any supplied tool for later maintenance. After two weeks, check and tighten any loose hardware and repeat again every six months thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.




FAILURE TO FOLLOW THE GUIDELINES ABOVE MAY RESULT IN INJURY AND/OR PROPERTY DAMAGE.




Before you begin, please read Page 2 of "Assembly and Care Advice".

And remember, do not tighten until each step is completed or instructed.


Parts List




#1 x 1pc
Table Top




#2 x 1pc
Table Top Support Panel



#3 x 1pc
Leg Support




#4 x 1pc
Base




#5 x 4pcs
Foot


Hardware List




#A x 12pcs
Bolt Ø5/16" X 2"



#B x 12pcs
Flat Washer




#C x 12pcs
Lock Washer



#D x 1pc
Allen Wrench M5



#A x 4pcs
#B x 4pcs
#C x 4pcs




1. Place the leg support (#3) face down onto a protected surface.

2. Prepare 4 bolts by first inserting a lock washer (#C) onto the bolt (#A) then a flat washer (#B) onto that same bolt (#A).

3. Place the base (#4) face down onto the leg support (#3), then insert 4 bolt assemblies into the center. Secure using the Allen wrench (#D). After that insert the threaded ends of the foot (#5) into the corner holes. Turn right to tighten.



#A x 4pcs
#B x 4pcs
#C x 4pcs



1. Turn the bottom assembly upright.


2. Prepare 4 bolts by first inserting a lock washer (#C) onto the bolt (#A) then a flat washer (#B) onto that same bolt (#A).

3. Place the support panel (#2) onto the top of the leg support (#3), then insert 4 bolt assemblies into the center holes. Secure using the Allen wrench (#D),



3. Adjust the levelers according to the ground level.

#A x 4pcs
#B x 4pcs
#C x 4pcs




2. Prepare 4 bolts by first inserting a lock washer (#C) onto the bolt (#A) then a flat washer (#B) onto that same bolt (#A). Insert a bolt into each corner and secure using the Allen wrench (#D).

1. Place the table top (#1) face down, then place the support panel (#2) face down onto the center of the table top.



Turn the table upright and make sure all parts are firmly secured.



ASSEMBLY IS COMPLETED