


ASSEMBLY INSTRUCTION

ITEM NO.N715P397332

ITEM NO.N715P397333

Dining Chair



ASSEMBLY INSTRUCTION

ITEM NO.N715P397332

ITEM NO.N715P397333

Please read these instructions fully before starting assembly:

1. Place all wooden parts on a clean and smooth surface such as a rug or carpet to avoid scratching the parts.
2. Kindly follow the assembly instructions step by step.
3. Do not tighten all screws and bolts until the table is fully assembled.
4. Unscrew the protective plastique supports from the metal insert of the table legs before assembly.
5. Parts of the assembly will be easier with 2 people.


Care and maintenance:

Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.

ASSEMBLY INSTRUCTION

ITEM NO.N715P397332

ITEM NO.N715P397333



ASSEMBLY INSTRUCTION


ITEM NO.N715P397332

ITEM NO.N715P397333

Part List

Ⓐ


ITEM NO.N715P397332



CUSHION SEAT (6 pcs)

Ⓑ

ITEM NO.N715P39733



CHAIR BACK (6 pcs)

Ⓒ

ITEM NO.N715P397333



FRONT LEGS (12 pcs)


ASSEMBLY INSTRUCTION

ITEM NO.N715P397332

ITEM NO.N715P397333

Hardware List


①



Ø 1/4" x 40mm

BOLT (12pcs)


②



Ø 1/4" x 45mm

BOLT (24 pcs)


③



Ø 1/4" x 60mm

BOLT (24 pcs)


④



Ø5/16" x 13mm

LOCK WASHER (60 pcs)

⑤



Ø5/16" x 19x 2 mm

FLAT WASHER (60 pcs)

⑥



4mm


ALLEN KEY (6pcs)

ASSEMBLY INSTRUCTION

ITEM NO.N715P397332


ITEM NO.N715P397333

STEP 1:



BOLT Ø 1/4" x 40 mm	BOLT Ø 1/4" x 60 mm	FLAT WASHER Ø5/16" x 13 mm	LOCK WASHER Ø5/16" x 19 x 2 mm	ALLEN KEY 4 mm
				
① x 12	③ x 24	④ x 36	⑤ x 36	⑥ x 6

STEP 2:



BOLT Ø 1/4" x 45 mm	FLAT WASHER Ø5/16" x 13 mm	LOCK WASHER Ø5/16" x 19 x 2 mm	ALLEN KEY 4 mm
			
② x 24	④ x 24	⑤ x 24	⑥ x 6

ASSEMBLY INSTRUCTION

ITEM NO.N715P397332

ITEM NO.N715P397333

COMPLETE

