












ASSEMBLY INSTRUCTION


ESPRESSO WOOD TOP STORAGE TABLE

A Table Top  1pc	B Bottom  1pc	C Leg  4pcs	D Bolt 5/16", 7/8"  4pcs	E Bolt 5/16", 7/8"  8pcs
F Bolt 5/16", 2"  4pcs	G Lock Washer  4pcs	H Flat Washer  10pcs	I Allen Wrench  1pc	J Metal  4pcs




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from damage.


1 Attach the metal (J) to the legs (C) by using the bolts (D), with the allen wrench (I).




2 Attach the legs (C) to the table top (A) by using the bolts (E), lock washer (G) and flat washer (H) with the allen wrench (I).



3 Attach the bottom (B) to the legs (C) by using the bolts (F), lock washer (G) and flat washer (H) with the allen wrench (I).



4 As shown, the shake handhandle is installed in the right side



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.