

Drawer Removal and Re-Installation

Drawer Removal -- Full-Extension Slides

1. Open the drawer fully.
2. Locate the quick disconnect levers on the right and left-hand slides.
3. Simultaneously press the quick disconnect levers (as shown) while pulling out the drawer.

SLIDE LEVERS UP OR DOWN ON BOTH SIDES OF DRAWER



Drawer Re-Installation

1. Locate the ball bearing cartridge on the right and left-hand slides. Slide the cartridges to the front of the respective slides.
2. On both sides, align the ears on the back end of the inner slide rails (attached to the drawer) with the grooves in the main body of the slides.
3. Once aligned on both sides, push in the drawer until fully closed. There will be resistance in initially re-installing and closing the drawer – this is normal.
4. Re-open and re-close the drawer a few times. If the drawer still does not open and close smoothly, the inner rail may not have been fully lined up with the grooves.