








TUN01OCL	TUN011KC	TUN026	TUN030AG	TUN020SD
A  Cam Lock 25Pcs+5Pcs(spare)	B  Klix Cam 25Pcs+5Pcs(spare)	C  Dowel 16Pcs+2Pcs(spare)	D  Adjustable Glide 4Pcs	E  Shelf dowel 12Pcs+2Pcs(spare)

STEP1




IMPORTANT:

FUNCTION OF KLIX CAM




1/4 RIGHT
TURN FOR
LOCKING



MAKE SURE THE ARROW IS
POINTING UPWARDS
BEFORE INSERTING INTO
THE PANEL'S HOLE.




STEP2



STEP3



COMPLETED ASSEMBLY



TWO PEOPLE ARE REQUIRED TO
ASSEMBLE AND MOVE THIS MODEL

IMPORTANT NOTE:

- Place all laminated parts on a clean and smooth surface such as a rug or carpet to avoid the parts from being scratched.
- Check to be sure that you have all parts and hardware.
- Remove all wrapping materials, including staples & packing straps before you start to assemble.
- Don't tighten all screws/bolts until all completely assembled.
- Keep all hardware parts out of reach of children.
- It is recommended to require 2 persons to complete the assembly.