

Assembly Instructions


Caution : You must read this before you proceed

Care & Maintenance




- ⊘  • Not for commercial use. For residential use only.
 - ✓  • Furniture may scratch floors. We recommend using furniture pads to protect your floors.
 - ⊘  • Do not put hot items directly on furniture surface.
 - ⊘  • Do not clean furniture with harsh cleansers or polish.
 - ⊘  • Do not place furniture under direct sunlight.
 - ⊘  • Do not place furniture near heating or cooling vents.
 - ⊘  • Do not write on furniture without a padded barrier to protect the surface.
 - ⊘  • Do not place furniture outside . For indoor use only.
 - ⊘  • Stains may be removed with mild soap solution and damp cloth.
 - ⊘  • Children should not climb or jump on the furniture.
-
- ✓  • Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in chair seat for hardware packs and legs.
Sets often ship in multiple boxes and may arrive a day or two apart.


CLUB CHAIR



Parts List


Label	Picture	Description	QTY
A		Backrest	1
B		Chair Seat	1
C		Armrest	1
D		Leg	2

Hardwares

Label	Picture	Description	QTY
①		Bolt (M8*100MM)	5
②		Washer(M8)	7
③		Spring Washer(M8)	7
④		Allen Wrench	1
⑤		Bolt (M8*100MM)	5
⑥		Wrench	1
⑦		Nut(M8)	3

Assembly Preparation

Before
Beginning
Assembly:



- Read instructions, cover to cover-



- Have 2 adults on hand for assembly-



- Do not assemble on flooring or carpet-




- Assemble on a clean non-marring surface (packing foam)-



- Save all packaging until finished-

Assembly Steps




This Club Chair has multiple parts and may require up to 30 minutes to assemble.

To give you an overview of the Chair, the above picture is to help you put the various parts into perspective.

Please read through the instructions below to familiarise yourself with the parts and steps before assembly.

Note: It is recommended that you have an adult partner to assist during the entire assembly process.


Step 1



Position the Backrest(A), Chair Seat(B), Armrest(C), Leg(D) and Hardware on a clean, non-marring surface, as shown.


Do not place on surface that can scratch or damage the upholstery.

Step 2



Pre-install the Bolts. Screw in the bolts as above picture showed.

Step 3



With assistance from an adult partner, lift the Backrest(A) up, Align the assembly holes to which on the Chair Seat(B). Insert the bolts which on Backrest(A) into Chair Seat(B). Screw up the Backrest(A) to the Chair Seat(B) using Nut(⑦), Spring Washers(③), and Washers(②) with the Wrench(⑥).

Step 4

4.1


Backrest(A)

Armrest(C)

Chair Seat (B)



4.2



With the assistance from your adult partner:


4.1) Insert the armrest into the pre-installed screw on the backrest.

4.2) Attach Armrest(C) to the assembled Chair Seat (B) using Bolt(①), Spring Washers(③), and Washers(②) with the Allen Wrench(④) as pictured above.

NOTE: Please don't tighten the bolts completely.


After leveling the chair (Step6). You can tighten the bolts completely.

Step 5



Install the Leg(D) onto the bottom of the chairseat.

Step 6



Put your Club Chair on a flat, level surface.
If wobbling, you can adjust the seat position a little to leveling.
Then tighten the bolts in the seat to the Arm.
Your Club Chair is ready for use.