







OPERATING INSTRUCTIONS

Assembly Instructions

AX1PC	CX1PC	DX2PCS
		
BX1PC	aX12PCS	
		

STEP 01



STEP 02

