

ASSEMBLY INSTRUCTIONS

TOOLS REQUIRED:

Allen Wrench (supplied, part # D)

BEFORE YOU START:


1. Check the parts against the parts list to make sure all items are present.
2. Assemble your furniture on a soft, flat surface to avoid scratching the finish.
3. **CAUTION:** Do not over tighten screws, nuts or bolts during assembly.
4. Your furniture may require occasional tightening.

INSTRUCTIONS:


Step 1. Attach two leg half panels to the leg full panel as shown in Figure 1.

Step 2. Align grain direction & follow stickers direction. Make all shelves in the same direction. Attach shelf panels to leg panels, tighten Bolt (A), Lock Washer (B) and Flat Washer (C) by using Allen Wrench (D) as shown in Figure 2.

Step 3. Turn the table top upside down on to a clean, soft surface. Align grain direction with shelf & follow sticker direction. Attach frame to the table top, tighten Bolt (A), Lock Washer (B) and Flat Washer (C) by using Allen Wrench (D) as shown in Figure 3.



376-911



376-916

Figure 1




Figure 2









Figure 3



No.	HARDWARE LIST		Q'ty
A		Bolt (Ø5/16"x1-3/4")	24
B		Lock Washer (Ø5/16")	24
C		Flat Washer (Ø5/16"*19*1.5mm)	24
D		Allen Wrench (100*50*4mm)	1