


PHO_10EKP2H
PHO_10EK6C2T

Assembly Instruction



Trouble shooting:

Missing / Wrong / Broken parts and installation issues



Send email with your question, pic and order number. to
support@idealhouse.vip



Respond within 24 hours




Issue resolved

YOU NEED

1. Tools required

A Phillips head screw driver is required for the assembly of this product, (not included) Electric tool should not be used to assemble this product.



2. Two people are needed



Tips!



1. Check all the components & screws are intact before assembling .
2. If you notice any pieces are missing or damaged please do not assemble and contact us immediately .
3. Please send an email with your order number and issues, we will respond within 24 hours. Customer Service Team: support@idealhouse.vip

IMPORTANT SAFETY INFORMATION

.Please carefully read the following instructions and caution warnings before assembling the product.

.Following this guide will ensure that you install, use and maintain the product properly.

.Please keep this installation and user manual/instructions for future reference in case you need to disassemble the product.

.Never allow children to climb onto the product. Ensure that you have special safety measures when children are around on their own.

.Be sure to check that all parts of the product are intact after you open the package.

.Do not assemble if you notice serious damage such as cracks or bends.

.During installation, please use work gloves for hand safety.

.Please assemble the unit on carpeted floor or the flat cardboard box to avoid scratching the surface or your floor while assembling on the floor.

.To assemble, please use the complimentary installation tools (Phillips screwdriver). Pay more attention to the direction of components at each step.

.It is recommended that two people work together to assemble the product.

RETURN POLICY

.Please contact us directly within 30 days after receiving.

.Ensure the product is in a good condition with the original box and all original certificates of purchase, manuals, and accessories attached.


How to maintain your product

.Check the screws of the product are not loose from regular use.:













.Do not use sharp instruments, rubbing alcohol, corrosive chemicals, or abrasive cleaners to clean the item.

COMPONENTS ID Nr.

Part Nr.	QTY	Part Nr.	QTY	Part Nr.	QTY
1	1 PC	5	1 PC	9	1 PC
2	1 PC	6	2 PCS	10	2 PCS
3	1 PC	7	1 PC	11	1 PC
4	1 PC	8	1 PC	12	2 PCS



HARDWARE LIST


Ax26+2  M6 x 35mm	Bx26+2  Ø15 x 11mm	Cx28+2  Ø8 x 30mm	Dx4  M6 x 48mm	Ex2  M4 x 25mm
Fx1  200*30*10mm	Gx1  M4	Hx5  M5*19mm	Ix2  Ø35mm	Jx6  M6 x 55mm
Kx8  15*15*10mm	Lx8  M3 x 16mm	Mx2  M3.5 x 12mm	Nx1  40*15*7mm	Ox2  190*20mm
Px2  Ø8 x 40mm	Qx2  M4 x 16mm	Rx2  M4 x 38mm	Sx12+1  M3.5 x 14mm	

1

M6 x 35mm



Ax4



x 2

2

Ø15 x 11mm




Bx4

Ø8 x 30mm



Cx4



3

Ø8 x 30mm



Cx4

M4




Gx1

M6 x 55mm



Jx6




4

M6 x 35mm



Ax6




5

M6 x 35mm



Ax6



6

Ø15 x 11mm




Bx3

Ø8 x 30mm



Cx2



7

Ø15 x 11mm




Bx3

Ø8 x 30mm



Cx2



8

Ø15 x 11mm




Bx4

Ø8 x 30mm



Cx8




9

M6*48mm



Dx4




10


Ø15 x 11mm



Bx2



11




12

M5*19mm



Hx5




13

Ø8 x 30mm



Cx8



14

M6 x 35mm




Ax10

M3.5 x 12mm




Mx2

40*15*7mm



Nx1




15

Ø15 x 11mm



Bx8




16

Ø15 x 11mm




Bx2




17

15*15*10mm  Kx8	M3 x 16mm  Lx8		
--	---	--	--



18

Ø35mm





Ix2

M3.5 x 14mm




Sx4




19

M4 x 25mm




Ex2

200*30*10mm



Fx1




20



M3.5 x 14mm





Sx8





When the clearance of the door is uneven, Adjust the cabinet door according to the figure.



Up and down adjustment by loosening the screws on the mounting plate.



In and out adjustment by loosening the screws on the hinge arm.



Side to side adjustment using the front adjustment screw on the hinge.

21

190*20mm




Ox2

M4 x 16mm




Qx2




22

Ø8 x 40mm








Px2

M4 x 38mm




Rx2



23

--	--	--	--



IMPORTANT SAFETY INFORMATION

Please carefully read the instructions and caution warnings below before assembling the product. Following this guide will ensure that you install, use and maintain the product properly.

- Please keep this installation and user manual/instructions for future reference in case you need to assemble the product.
- Do not assemble if you notice serious damage such as cracks or bends.
- During installation, please use work gloves for hand safety.
- Please assemble the unit on carpeted floor or the flat cardboard box to avoid scratching the surface or your floor while assembling on the floor.
- To assemble, please use the complimentary installation tools (Allen Wrench). Pay more attention to the direction of components at each steps.
- It is recommended that two people work together to assemble the product.
- Please do not tighten the screws up too much, just to 80% before you finish to make the installation go on successfully.

RETURN POLICY

We believe you will absolutely love your new product. But for some reason you want to return your item, please contact us within 30 days after receiving and ensure that the product which you want to return is in a good condition in the original box with all original certificates of purchase, manuals and accessories attached.

HOW TO MAINTAIN YOUR PRODUCT:

- Check the screws of the product are not loose from regular use.
- Do not use sharp instruments, rubbing alcohol, corrosive chemicals, or abrasive cleaners to clean the product.
- Do not keep the product in a damp environment for a long period of time. The damp environment may cause the iron components to rust and the plates to bulge and crack.

How to find us?

Customer Service

Email: support@idealhouse.vip