



Item: Recliner

SKU:N719P243150




PART LIST


A



B




C



C1
back ears


C2

D




arm pads


E




F




a




b




G




H




I



1




2




hold the handle of the arm
and pull hard to make it stretch
out, when you need fold it pull
hard from the bottom and push
the top at the same time




3



4





5






please put seat cushion to the center of seat correctly
and tight with Velcro



6





7




8




B













9



10






11




BLACK

12



13



14

