


GAME TABLE


User Manual




DJ504538










Warning : Please read this instruction manual carefully before using the product.

version: 1.0


Package Contents

Plates and iron components	Assembly tool kit	Instruction manual


Precautions ⚠




1.Avoid long-term direct sunlight exposure




2.Stay away from fire




3.keep away from sharp objects




4.Keep infants/children away from assembly parts to avoid choking and suffocation.




5.keep away from corrosive substances



6.Pay attention to avoid cver-tightening fasteners, orthey may induce cra-cking within the board.



7.Prevent objects from being damaged by immersion in water




8.Prevent object collision and damage


















9.Be careful to avoid collisions

Disassembly Diagram



Parts List

1  x 2	2 	3 
4  x 2	5 	6 
7  x 2	8 	9 
10 	11  x 2	12  x 2
13 	14 	15  x 2


Parts List

16




x 2

17




x 2

18




x 3

19




x 3

20




x 3

21




x 3

22


















x 12

23



x 2

Tool sheet

A M6  X6+1	B M6x10MM  X10+2	C M6x25MM  X38+4	D ST6x50MM  X12+2
E ST4x10MM  X2+1	F ST4x10MM  X24+3	G M4x6MM  X12+2	H  X6
I M6  X4+1	J  X2	K  X1	L  X1
M  X4	N  X1	O M4  X1+1	P  X1

ASSEMBLY INSTRUCTION

Attention: The shelves can be installed on either side, you can choose one lnstruction as you prefer.

1L-24L:The high bookshelf is on the left.





1R-24R:The high bookshelf is on the right.





ASSEMBLY INSTRUCTION


L-1













A	x6
	
M6	


ASSEMBLY INSTRUCTION

L-2





F	x4
ST4x10MM	


L-3




Tighten the F screw by 70%








Pay attention to the direction of the track stopper

F	x6
	
ST4x10MM	

L-4




Pay attention to the position of the hole indicated by the arrow


Tighten the C screw by 99%

C	x4
M6x25MM	


ASSEMBLY INSTRUCTION


L-5




F	x8
	
ST4x10MM	

L-6







Tighten the C screw by 99%


C	x4
	
M6x25MM	

L-7



C	x2
	
M6x25MM	


L-8




B	x4
M6x10MM	

ASSEMBLY INSTRUCTION


L-9




B	x4
	
M6x10MM	

ASSEMBLY INSTRUCTION


L-10



Tighten the F screw by 70%




Pay attention to the direction of the track stopper


F	x6
	
ST4x10MM	

ASSEMBLY INSTRUCTION


L-11



Tighten the C screw by 99%





All F screws are tightened by 99%



C	x4
M6x25MM	


L-12




D	x4
	
ST6x50MM	

L-13


Pay attention to the position of the hole indicated by the arrow




C	x8
	
M6x25MM	


ASSEMBLY INSTRUCTION


L-14



C	x2
	
M6x25MM	


L-15




D	x8
	
ST6x50MM	


ASSEMBLY INSTRUCTION


L-16



I	x4
M6	
C	x4
	
M6x25MM	


L-17




C	x5
	
M6x25MM	


ASSEMBLY INSTRUCTION

L-18





Cut the light strip to the appropriate length with scissors



L	x1
	



L-19




C	x5
	
M6x25MM	




ASSEMBLY INSTRUCTION


L-20

E	x2
	
ST4x10MM	
K	x1
	





L-21

J	x2
	
M6	
M	x4
	
B	x2
	
M6x10MM	



L-22




G	x12
	
M4x6MM	
H	x6
	


L-23





ASSEMBLY INSTRUCTION


R-1














A	x6
	
M6	

ASSEMBLY INSTRUCTION


R-2

Pay attention to the direction
of the track stopper






Tighten the F
screw by 70%

F	x4
	
ST4x10MM	


ASSEMBLY INSTRUCTION

R-3



F	x6
ST4x10MM	


R-4



C	x4
M6x25MM	


ASSEMBLY INSTRUCTION


R-5




F	x8
ST4x10MM	


R-6




C	x4
	
M6x25MM	

R-7



C	x2
	
M6x25MM	


R-8




B	x4
M6x10MM	

ASSEMBLY INSTRUCTION


R-9



B	x4
	
M6x10MM	

ASSEMBLY INSTRUCTION


R-10




F	x6
ST4x10MM	

ASSEMBLY INSTRUCTION


R-11



Tighten the C screw by 99%




All F screws are tightened by 99%




C	x4
M6x25MM	

ASSEMBLY INSTRUCTION


R-12




D	x4
	
ST6x50MM	

ASSEMBLY INSTRUCTION


R-13




C	x8
	
M6x25MM	


ASSEMBLY INSTRUCTION


R-14



C	x2
	
M6x25MM	


R-15





D	x8
	
ST6x50MM	


ASSEMBLY INSTRUCTION


R-16



I	x4
	
M6	
C	x4
	
M6x25MM	


R-17




C	x5
	
M6x25MM	


ASSEMBLY INSTRUCTION

R-18







Cut the light strip to the appropriate length with scissors

L	x1
	


R-19





C	x5
	
M6x25MM	


ASSEMBLY INSTRUCTION




R-20




E	x2
	
ST4x10MM	
K	x1
	


R-21



J	x2
	
M6	
M	x4
	
B	x2
	
M6x10MM	

R-22



G	x12
	
M4x6MM	
H	x6
	

R-23




Customer Service

3-years Warranty



We guarantee your product is free from defects in product material and workmanship for three(3) years starting from the date of purchase during normal use of household conditions.If your appliance fails to operate properly within our warranty period,We will send the corresponding accessories,Replacement is free and all shipping costs are covered.

Quick Response within 24 Hours



If you are still unable to resolve the issue you are experiencing, please contact us immediately via our support email. It doesn't matter if the product has been installed or not, our customer support team will respond within 24 hours and assist you quickly and efficiently. The most efficient way to confirm your problem to us is to attach a video, which illustrates your product issues.

Problems You May Encounter

PART	PROBLEM	SOLUTION
whole Product	Parts are missing, defective or having wrong parts in package.	You can contact us and we will get back to you within 24 hours
	Having issue(s) while reading the instruction or completing the assembly.	Feel free to contact us and we will get back to you within 24 hours.
	Encountering non-human caused damage during usage.	If the product is damaged due to non-human causes, please keep the product and send us photos of it.We will ascertain the cause of the product damage within 48 hours and provide you with a satisfactory solution.
Table Surface	Board Surface is broken, scratched or lack of somescrew holes.	Feel free to contact us and we will get back to you within 24 hours.
	The screw holes on the wooden board and other wooden boards are not aligned.	1.Please tighten the screws on the board by 70%, do not tighten completely. 2. Adjust the wooden board and board.Until the holes are arranged neatly, then tighten all screws
	Desktop misalignment and unevenness	1.Please tighten the screws connecting the table board to the elevator by 70%, do not tighten them completely. 2.Adjust to a flat and aligned desktop, then tighten the screws. 3.If your problem still can’t be solved, please feel free to contact us.
Metal acce--ssories	Metal accessories are damaged, rusted, bent, and broken.	Feel free to contact us and we will get back to you within 24 hours.
	The table is unstable after being assembled.	1.Check if the screws are tightened. 2.Read throughout the manual, check are there any parts installed incorrectly or missing assembled. 3.If your problem still can’t be solved, please feel free to contact us.
	Encountering non-human caused damage during usage.	If the product is damaged due to non-human causes, please keep the product and send us photos of it.We will ascertain the cause of the product damage within 48 hours and provide you with a satisfactory solution.