



BEATA 3



(D) Montageanleitung

(NL) Handleiding voor de montage

(TR) Montaj talimati

(F) Notice de montage

(CZ) Montážní návod

(GB) Assembly instructions

(HU) Szerelési útmutató










(PL) Instrukcja montażu


(RU) Инструкция по монтажу

(IT) Istruzioni di montaggio

(SK) Návod na montáž





(RO) Instrucțiuni de montaj









Service • Assistenza • Dienstverlening • Serwis •
 Servis • Szerviz • Сервисная служба

Name • Nom • Nome • Naam • Nazwa • Jméno • Názov • Név • Denumire • Isim • Название	BEATA
Nr • No. • N° • Номер • Č • Sz	
Type • Tipo • Típus • Typ • Тип • Тір	3



A  X...	B  X...	C  X...	D  X...
--	--	--	--