





Assembly Instructions






X2





We recommend using hand tools for assembly.


If an electric screwdriver is used, reduce power and torque to avoid damage to the product.



Install the Anti-Tip Straps

Using the anti-tip straps can reduce the risk of tipping over, but can not eliminate it.



































⚠ Caution

Make sure all parts are included. Most board parts are labeled or stamped on the raw edge. Contact us for free replacement if having damaged or missing parts.



Parts List

		
1 1PC	2 1PC	3 1PC
		
4 1PC	5 1PC	6 2PCS
		
7 5PCS	8 4PCS	9 2PCS
		
10 1PC	11 1PC	


Hardware List

 <p>A 12PCS</p>	 <p>B 12PCS</p>	 <p>C Ø8×30m 12PCS</p>	 <p>D Ø1/4"×2" 4PCS</p>	 <p>E 1PC</p>
 <p>F Ø1/4"×1/2" 16PCS</p>	 <p>G 20PCS</p>	 <p>H 4PCS</p>	 <p>I Ø3.5×14mm 24PCS</p>	 <p>J 2PCS</p>
 <p>K Ø3×12mm 4PCS</p>	 <p>L 12PCS</p>	 <p>M Ø3×16mm 12PCS</p>	 <p>N 4PCS</p>	 <p>O Ø3×16mm 4PCS</p>
 <p>P 4PCS</p>	 <p>Q Ø3.5×35mm 4PCS</p>	 <p>R 2PCS</p>	 <p>S 1PC</p>	

1





D
4 pcs



E
1 pc

2







F
16 pcs

Tighten all screws.




Apretar todos los tornillos.

Serrez toutes les vis.


3





4



5




6




A
6 pcs


7



8




9



G
20 pcs

10




H
2 pcs

I
4 pcs



J
1 pc

K
2 pcs

11




11




H

2 pcs




I

2 pcs



J



1 pc




K

2 pcs


12



11



H




I

16 pcs

screws for adjusting the door
to achieve uniform
clearance around the door,
you may need to adjust the
door by tightening or
loosening the two screw on
the hinge itself

13



14

