






step 1






step 2





step 3





step 4





step 5





step 6



step 7






step 8









COMPUTER DESK SET

PART LIST

COMPUTER DESK



HARD WARE

A  x22	B  x13	C  x4
D  x4	E  x1	F  x22