


ASSEMBLY INSTRUCTIONS

TOOLS REQUIRED

No Tools Required For Assembly



**2 - Persons
Recommended**

ASSEMBLY RATING



EASY —————> DIFFICULT

The Assembly Rating is a 5-point system showing the level of effort needed to assemble a specific product.



CHECK BEFORE STARTING

☐

Are you missing anything?

Double-check all parts, hardware and accessories listed on Page 6 are accounted for.

☐

Check out our Quick Tips!

We recommend reviewing the pre-assembly handouts. Even experts need a refresher now and then!

☐

Should we send any replacements?

Are there any irregularities or flaws in the parts? We can send replacements!

☐

Prep Time!

Please review the assembly instructions and all diagrams prior to assembling. Arrange parts as recommended on Page 7 and group identical hardware together to make assembling easier.


PRE ASSEMBLY INTRODUCTION

We understand building ready-to-assemble furniture can be a challenging experience for some. To help avoid confusion, we have provided some helpful tips that may speed up the process.



Teamwork

ALWAYS have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.




Suitable Location

Assembling near the area of the intended location is highly recommended.




Sufficient Space

Make sure you have enough space to move around during the assembly.



Avoid Scratches

Use cardboard, blankets or a carpeted area while assembling furniture to prevent scratches.



Flat Surface

Make sure the furniture rests on a flat and level surface with each leg evenly touching the floor.


ASSEMBLY AND CARE ADVICE



**FAILURE TO FOLLOW THE GUIDELINES BELOW MAY
RESULT IN INJURY AND/OR PROPERTY DAMAGE.**




Position each part correctly
and insert screws or bolts into
their respective holes.



Turn clockwise to tighten and
only tighten when step is
completed or when instructed
to do so.



Use the appropriate hand tools
or power tools for assembly.
Select steps, such as tightening
screws and/or bolts, may require
hand tools to avoid causing
damage during assembly.



Save the instructions and store
any supplied tools for later
maintenance.


After two weeks, check and
tighten any loose hardware and
repeat again every six months
thereafter.

IT IS THE USER'S RESPONSIBILITY TO MAINTAIN THE FURNITURE. THE HARDWARE MAY LOOSEN OVER TIME AND MAY CAUSE THE FURNITURE TO BE WOBBLY AND UNABLE TO SUPPORT ITS INTENDED WEIGHT CAPACITY. THIS MAY LEAD TO COLLAPSE AND MAY CAUSE SERIOUS INJURY.

CORNER SOFA




- Please keep instructions for future reference.
- Check the quantity and irregularity of parts and hardware before you start.




PARTS

#1 1pc



Laf power Recling Chair

#2 6pcs



Head Rest

#3 4pcs




Wooden Leg

#4 29pcs




Plastic Leg with Washer

#5 1pc




Console

#6 2pcs




Armless Chair

#7 1pc



Corner

#8 1pc



Raf Power Recling Chair

#9 1pc



Ottoman

#10 2pcs



Transverter


#11 2pcs



Power Line

HARDWARE

#A 4pcs



Bolt

#B 4pcs




Lock Washer

#C 4pcs



Flat Washer

#D 1pc





Allen Wrench



ASSEMBLY INSTRUCTIONS

1

- Part **#1** x1pc
- Part **#2** x1pc
- Part **#3** x 2pcs
- Part **#4** x4pcs
- Hardware **#A** x4pcs
- Hardware **#B** x4pcs
- Hardware **#C** x4pcs





Remove parts in the bottom of the compartment. Align wooden legs (#3) to the corners of the seat (#1), then secure by using bolts (#A) with washers (#B,C). Secure plastic legs with washers (#4) to seat (#1). Attach headrest (#2) to seat (#1).





2

- Part **#5** x1pc
- Part **#4** x4pcs



Remove parts in the bottom of the compartment. Secure plastic legs with washers (#4) to console (#4).



PAY ATTENTION

All wires must be connected


ASSEMBLY INSTRUCTIONS

3

Part (#2) x 2pcs

Part (#4) x 8pcs

Part (#6) x 2pcs




4

Part (#2) x2pcs

Part (#4) x5pcs

Part (#7) x1pc



ASSEMBLY INSTRUCTIONS

5

Part #2 x1pc

Part #3 x1pc




Part #4 x4pcs

Part #8 x1pc


Hardware #A x4pcs

Hardware #B x4pcs

Hardware #C x4pcs





Remove parts in the bottom of the compartment. Align wooden legs (#3) to the corners of the seat (#8), then secure by using bolts (#A) with washers (#B,C). Secure plastic legs with washers (#4) to seat (#8). Attach headrest (#2) to seat (#8).





6

Part #4 x4pcs

Part #9 x1pc




Remove parts in the bottom of the compartment. Secure plastic legs with washers (#4) to seat (#9).



ASSEMBLY INSTRUCTIONS

7

Attach all components together by align and hooking the hooks on the ends together.



ASSEMBLY COMPLETED



Please ensure the furniture rests on an even and flat surface. If the product wobbles or feels loose, double-check all bolts and/or screws are properly tightened and secured.



Keep this handy!

Please retain this instruction manual and any order-related information for future reference.

8

Part #10 x 2pcs

Part #11 x 2pcs

