



A		1
B		1
C		1
D		1
X	M6*32	13
Y		13


Corner Sofa




Step 1








Step 2




Step 3




E		1
F		1
D		2
X	 M6*32	12
Y		12
Z		1

Armless sofe



Step 1



Step 2



Step 3



1

The cushion can be fastened to the rattan with the effective horn button.



2

Open the rattan and fasten the horn button to a chosen position.



3





Attached to a spare tape, the horn button allows the cushion to move freely.




4

Contact us for any further problems concerning the item.




E		2
F		2
D		4
X	 M6*32	24
Y		24


Step 1




Step 2








Armless sofa




Step 3




Coffee Table

J		1
K		2
L		2
M		1
X	 M6*32	12
Y		12
Z		1


Step 1





Step 2



Step 3



Coffee Table



1

The cushion can be fastened to the rattan with the effective horn button.



2

Open the rattan and fasten the horn button to a chosen position.



3

Attached to a spare tape, the horn button allows the cushion to move freely.



4

Contact us for any further problems concerning the item.

