


Assembly Instructions

PWS-PD2411-WNT

WALNUT FILE CABINET WITH 2 DRAWERS



THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Do Not Return This Product!

Contact our customer service team for help first.

Monday-Friday 9am - 5pm CST

Visit: support@cenports.com



WARNING

- Unit can tip over causing severe injury or death.
- Anchor unit to stud in wall (if instructed to).
- Do Not allow children to climb on unit.
- Put heavy items on lower shelves or drawers.



Contact Us!

Do NOT return this product!

Contact our friendly customer service team first for help



Visit support@cenports.com


Helpful Hints

PEOPLE NEEDED FOR ASSEMBLY: **1-2**


ESTIMATED ASSEMBLY TIME: **30 MINUTE**

- Open your item in the area you plan to keep it to avoid excessive heavy lifting.
- Identify, sort and count the parts before attempting assembly.
- Compression dowels are lightly tapped in with a hammer.
- Slides are labeled with a **R** (right) and **L** (left) for proper placement.
- Make sure to always face the point on the top of the Cam Lock towards the outer edge.
- Use all the nails provided for the back panel and spread them out equally.
- Back panel must be used to make sure your unit is sturdy.
- Do NOT use harsh chemicals or abrasive cleaners on this item.
- Never push, pull, or drag your furniture.









Before You Start



- ✓ Read through each step carefully and follow the proper order
- ✓ Separate and count all your parts and hardware
- ✓ Give yourself enough room for the assembly process
- ✓ Have the following tools: Flat Head Screwdriver, #2 Phillips Head Screwdriver and Hammer
- ✓ Caution: If using a power drill or power screwdriver for screwing, please be aware to slow down and stop when screw is tight. Failure to do so may result in stripping the screw.

Cam Lock Fastening System


This Cam Lock Fastening System will be used throughout the assembly process.



Board Identification


Not actual size

A




x1
SIDE PANEL LEFT

B




x1
SIDE PANEL RIGHT

C




x1
TOP PANEL

D




x1
BOTTOM PANEL

E




x1
CENTER LEFT PANEL

F




x1
CENTER RIGHT PANEL

G




x2
SHELF PANEL

H




x2
DRAWER FRONT PANEL

I




x2
DRAWER SIDE LEFT PANEL

J




x2
DRAWER SIDE RIGHT PANEL

K




x2
DRAWER BACK PANEL

Y




x2
BACKPLY PANEL

Y1



x1
CENTER BACKPLY PANEL

Z




x2
DRAWER BOTTOM PANEL

Part List

Not Actual Size



x12
Minifix Bolt




x12
Cam Lock
12-15



x16
Wood Dowel
6 X 30




x24
Csk Screw
3.5 X 15




x8
Csk Screw
4.7 X 38




x8
Euro Screw
6 X 9



x2 Set
Drawer Slide
350mm




x2
Caster Wheel with
Lock




x2
Caster Wheel
without Lock




x2
Handle
(96 hole)




x4
Csk Screw
4 X 25



x18
Backply Stopper



x18
Csk Screw
3.1 X 20




x4
Metal Rod



x8
Shelf Stopper




x8
Unitar Screw
6.3 X 40




x1
Allen Key M4


Step 1




Step 2




Step 3



Step 4




Step 5




Step 6


x4
Metal Rod




Step 7




Step 8



Step 9




Step 10



Step 11




x16
Csk Screw
3.5 X 15




x2
Caster Wheel with
Lock




x2
Caster Wheel
without Lock




Step 12



Step 13




Step 14




Step 15




x8
Shelf Stopper




Step 16



Step 17





Tips for Proper Care and Maintenance of Particle Board Furniture

Understanding Particle Board

Particle Board Composition:

Particle board is composed of wood particles, such as sawdust and wood chips, bonded together with adhesive under high pressure. The surface of particle board is typically covered with a laminate or veneer to enhance its appearance.

Sensitivity to Moisture:

One of the primary vulnerabilities of particle board is its sensitivity to moisture. Excessive exposure to water or high humidity can cause swelling, warping, or delamination.

Cleaning and Maintenance Guidelines

1. Dust Regularly:

Regular dusting is crucial to prevent the accumulation of dirt and grime on particle board surfaces. Use a soft, dry cloth or a duster to gently remove dust.

2. Avoid Excess Water:

Particle board should not be cleaned with excessive water or harsh cleaning agents. Use a slightly damp (not wet) cloth with a mild cleaner specifically designed for wood surfaces.

3. Protect from Direct Sunlight:

Prolonged exposure to direct sunlight can cause discoloration or fading of the particle board surface. Position furniture away from direct sunlight or use window coverings to reduce exposure.

4. Use Coasters and Mats:

Protect particle board surfaces from hot items, spills, and scratches by using coasters, placemats, or felt pads under objects. This precaution prevents damage and preserves the furniture's appearance.

5. Repair Minor Damage Promptly:

Address minor damage such as scratches or small chips promptly. You can use touch-up markers or putty to fill in and conceal minor imperfections. Ensure that the repair materials match the furniture's colour and finish.