
ASSEMBLY INSTRUCTION

CANOPY TWIN SIZE HEADBOARD AND FOOTBOARD CANOPY TWIN SIZE RAILS + REGULAR SLATS








1pc




This page lists all the contents included in the box. Please take the time to identify the hardware as well as the individual components to this product. As you unpack and prepare for assembly, place the contents on a carpeted or padded area to protect them from

Assemble the left lower posts (A) and the right lower posts (B) to the headboard panel (F) with 4pcs Bolt (K) then fastened using allen wrench (T).




Assemble the cushion (E) to the left lower posts (A) and the right lower posts (B) with 2pcs bolt (N), 2pcs bolt (O) with 4pcs bolt (P) and 4pcs flat washer (R) then fastened using allen wrench (T).



3


Assemble the left extention leg (C) and the right extention leg (D) to the footboard panel (G) with 4pcs bolt (M) then fastened using allen wrench (T).



Assemble the side rails (H) to the left lower post (A) and the right lower post (B) with 4pcs bolt (L) and 4pcs washer (Q); assemble the side rails (H) to the left extention leg (C) and the right extention (D) with 4pcs bolt (L) and 4pcs washer (Q); then fastened using allen wrench (T).


8pcs

8pcs




5

Assemble the slats (I) to the side rails (H) with 6pcs bolt (N) ,12pcs washer (Q) ,6pcs nuts (S), then fastened using allen wrench (T) and wrench (U).



Assemble the finial (J) to left lower posts (A) and right lower posts (B), left extention leg (C) and right extention leg (D).



Cleaning & Care

Treat surface with care. Surface is resistant to scratches but is not scratch resistant. Clean surfaces with a dry or damp soft cloth. Do not use abrasive cleaners. Hardware may loosen over time. Periodically check that all connections are tight.