

Instruction Manual

3 Pk Lamp Set

Questions?

E-mail our customer service department at
customerservice@alltherages.com

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other). As a safety feature to reduce the risk of electrical shock and fire, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter this safety feature. This lamp is for indoor use only. The lamp should not be used near water. Never immerse the lamp in water or other liquids. Never cover the lamp with any object including cloth or paper as this is a fire hazard. Do not handle the bulb immediately after the light is turned off as it will be hot. This is not a toy.


ASSEMBLY INSTRUCTIONS:

TABLE LAMP:

1. Screw socket (A) into Base (B)
2. Squeeze the harp (C) and insert into the harp saddle (D)
3. Remove the protective plastic from the lamp shade (E) and attach to the harp (C) by screwing the finial (F) to the harp (C).
4. Install bulb. Only use bulbs of specified type and maximum rated wattage or less.
5. Plug the electrical supply cord into the wall outlet.

FLOOR LAMP:

1. Screw pole (A) to base (B), then screw pole (C) to pole (A).
2. Screw pole (D) to pole (C), screw lamp body (E) to pole (D),
3. Squeeze the harp (G) and insert into the saddle (F).
4. Remove the protective plastic from the lamp shade (H) and attach to the harp (G) by screwing the finial (I) to the harp (G).
5. Install bulb. Only use bulbs of specified type and maximum rated wattage or less.
6. Plug the electrical supply cord into the wall outlet.



EACH USES 1X 100W MAX MEDIUM BASE TYPE A BULB
(NOT INCLUDED)

CLEANING & MAINTENANCE:

1. Unplug the fixture before cleaning.
2. Use a clean, dry, soft, lint-free cloth.
3. Do not use water or other chemical cleaning agents.

Manuel d'instructions

Ensemble de 3 lampes

Des Questions?

E-mail notre service clientèle à:

customerservice@alltherages.com

CONSIGNES DE SÉCURITÉ IMPORTANTES:

Cette lampe portable a une fiche polarisée (une lame est plus large que l'autre). En tant que dispositif de sécurité pour réduire le risque de choc électrique et d'incendie, cette fiche ne peut être branchée dans une prise polarisée que dans un sens. Si la fiche ne rentre pas complètement dans la prise, inversez-la. Si elle ne rentre toujours pas, contactez un électricien qualifié. Ne jamais utiliser avec une rallonge à moins que la fiche ne puisse être complètement insérée. Ne modifiez pas cette fonction de sécurité.

Cette lampe est destinée à un usage intérieur uniquement. La lampe ne doit pas être utilisée près de l'eau. Ne plongez jamais la lampe dans l'eau ou d'autres liquides. Ne couvrez jamais la lampe avec un objet, y compris un chiffon ou du papier, car cela présente un risque d'incendie. Ne manipulez pas l'ampoule immédiatement après avoir éteint la lumière car elle sera chaude. Ce n'est pas un jouet.


INSTRUCTIONS DE MONTAGE:

LAMPE DE TABLE:

1. Vissez la douille (A) dans la base (B)
2. Serrez la harpe (C) et l'insert dans la selle de harpe (D)
3. Retirez le plastique protecteur de l'abat-jour (E) et fixez-le à la harpe (C) en vissant le fleuron (F) sur la harpe (C).
4. Installez l'ampoule. Utilisez uniquement des ampoules du type spécifié et d'une puissance nominale maximale ou inférieure.
5. Branchez le cordon d'alimentation électrique dans la prise murale.

LAMPADAIRE:

1. Vissez le poteau (A) à la base (B), puis vissez le poteau (C) au poteau (A).
2. Vissez le poteau (D) au poteau (C), vissez le corps de la lampe (E) au poteau (D),
3. Serrez la harpe (G) et insérez-la dans la selle (F).
4. Retirez le plastique protecteur de l'abat-jour (H) et fixez-le à la harpe (G) en vissant le fleuron (I) sur la harpe (G).
5. Installez l'ampoule. Utilisez uniquement des ampoules du type spécifié et d'une puissance nominale maximale ou inférieure.
6. Branchez le cordon d'alimentation électrique dans la prise murale.



EACH USES 1X 100W MAX MEDIUM BASE TYPE A BULB
(NOT INCLUDED)

