DINING SIDE CHAIR

ASSEMBLY INSTRUCTIONS



ASSEMBLY INSTRUCTIONS

ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



Warning!

- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.





ASSEMBLY TIME

15 MINUTES

PARTS IDENTIFICATION

	PART NAME	FIGURE	QTY
A	BACK FRAME		1PC
В	FRONT LEG FRAME		1PC
С	LEFT SIDE RAIL		1PC
D	RIGHT SIDE RAIL		1PC
E	SEAT CUSHION		1PC

HARDWARE IDENTIFICATION

	HARDWARE NAME	FIGURE	QTY
1	ALLEN WRENCH (4MM - BLK)		1PC
2	BOLT (Φ4/17" x 2"- RBW)		6PCS
3	NYLON WASHER (3/5" x 3/5" - BLK)	(e)	6PCS
4	FLAT HEAD SCREW (Φ3/19" x 1" - RBW)	-community	4PCS

NOTE: QUANTITIES SHOWN ARE FOR ONE CHAIR NOTE: PHILLIPS HEAD SCREW DRIVER IS REQUIRED IN THE ASSEMBLY PROCESS;

HOWEVER, MANUFACTURER DOES NOT PROVIDE THIS ITEM.

ASSEMBLY INSTRUCTIONS

