

ASSEMBLY INSTRUCTION

1

2

3

4

↻ leveling bolt

Ax1 	Bx1 	Cx4 	Dx1 	Ex4 	Fx4
Gx4 	Hx4 <p>8x18mm</p>	Ix4 <p>6x18mm</p>	Jx1 <p>5mm</p>	Kx1 <p>4mm</p>	