


Kitchen Island Cart

Assembly Instructions - Please keep for future reference



Important - Please read these instructions fully before starting assembly




Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on the following pages.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- During assembly do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.



- To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

- Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts
- Regularly check and ensure that all bolts and fittings are tightened properly.

WARNING

In order to help prevent overturning – please follow these instructions

To help prevent product toppling over please follow the below steps:-




















Use the anti tip strap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose

Components - Fittings

Please check you have all the panels listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases, more fittings may be supplied than required.


HARDWARE BOX INSIDE BOX 2

A QTY: 47 	B QTY: 47 	C QTY: 30  Ø6*25mm	D1 QTY: 6 
CAM BOLT	CAM LOCK	WOOD DOWEL	BALL BEARING GLIDE
D2 QTY: 6 	E QTY: 36  Ø6*12mm	F QTY: 13  1/4"x32mm	G QTY: 6 
BALL BEARING GLIDE	FLAT HEAD SCREW	BOLT	SPRING WASHER
H QTY: 6 	I QTY: 12  Ø6*25mm	J QTY: 7 	K QTY: 14  Ø8*12mm
FLAT WASHER	FLAT HEAD SCREW	HANDLE	HANDLE BOLT
L QTY: 8 	M QTY: 90  Ø7*15mm	N QTY: 7 	O QTY: 12 
HINGES	FLAT HEAD SCREW	HINGES	SHELF PIN
P QTY: 8  Ø7*15mm	Q QTY: 4 	R QTY: 18  Ø8*25mm	S QTY: 1 
PAN HEAD SCREW	CASTER	FLAT HEAD SCREW	CAMTOOL
T QTY: 1 	U QTY: 2 	V QTY: 16  1/4"x12mm	
ALLEN KEY	SPING BALL LATCH	BOLT	

Using Camlocks


Step 1

Connect the male camlock as directed in the assembly instructions using a screwdriver.



Step 2


Push the male camlock into the entry hole.



Step 3

Insert the female camlock as shown in the instruction.

Note: ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.




Step 4

Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.



The joint is now secure.




Slides Must Be Separated Berore Assembly.
After Separated, Set Aside Until Needed for Assembly.

Pay attention when connecting !
The sliding module must be at the front end.


STEP 1 : Extend Side



STEP 2 : Push Lever UP




Push lever for the left of drawer,
press the lever for the right of drawer.





STEP 3 : Remove Runner

Assembly Instructions


Tool required



Phillips screw driver
(medium & large)


















x2






Assembly Instructions

BOX 1 : N707P404588










1 	2 	5 
LEFT SIDE FRAME QTY: 1	RIGHT SIDE FRAME QTY: 1	FRONT PANEL - MIDDLE QTY: 1
6 	7 	11 
FRONT PANEL - LEFT QTY: 1	FRONT PANEL - RIGHT QTY: 1	LEFT EXTENSION SUPPORT QTY: 1
12 	13 	15 
RIGHT EXTENSION SUPPORT QTY: 1	BRACKET QTY: 2	BRACKET - LEFT QTY: 1
16 	17 	19 
BRACKET - RIGHT QTY: 1	BRACKET BOTTOM QTY: 1	MIDDLE ADJUSTABLE SHELF QTY: 1
20 	30 	31 
LEFT/RIGHT ADJUSTABLE SHELF QTY: 2	DRAWER FRONT QTY: 2	DRAWER LEFT QTY: 3

Assembly Instructions

BOX 1 : N707P404588










32		35		36				
DRAWER RIGHT		QTY: 3	DRAWER FRONT		QTY: 1	DRAWER BACK		QTY: 1

BOX 2 : N707P404589

3		4		9				
CENTER PANEL - LEFT		QTY: 1	CENTER PANEL - RIGHT		QTY: 1	TOP PANEL		QTY: 1
10		21		22				
EXTENSION TOP PANEL		QTY: 1	BOTTOM PANEL		QTY: 1	FRONT BASE RAIL		QTY: 1
23		24		25				
BACK BASE RAIL		QTY: 1	LEFT SIDE BASE RAIL		QTY: 1	RIGHT SIDE BASE RAIL		QTY: 1




Assembly Instructions

BOX 2 : N707P404589

8 	14 	18 
DOOR STOPQTY: 3	PULL BARQTY: 4	BACK PANELQTY: 1
26 	27 	28 
BASE FRAME CONNECTORQTY: 2	BASE FRAME CONNECTORQTY: 3	LEFT DOORQTY: 2
29 	33 	34 
RIGHT DOORQTY: 2	DRAWER BACKQTY: 2	DRAWER BOTTOMQTY: 2
37 		
DRAWER BOTTOMQTY: 1		

ASSEMBLY INSTRUCTIONS


STEP 1




A		2PCS
D1		2PCS
E		6PCS

ASSEMBLY INSTRUCTIONS

STEP 2




STEP 3




ASSEMBLY INSTRUCTIONS

STEP 4



B		4PCS
C		4PCS
S		1PC


STEP 5




B		2PCS
C		2PCS
S		1PC

ASSEMBLY INSTRUCTIONS

STEP 6




STEP 7




A		8PCS
---	---	------

ASSEMBLY INSTRUCTIONS

STEP 8




STEP 9



A		3PCS
C		2PCS


ASSEMBLY INSTRUCTIONS

STEP 10



B		3PCS
F		7PCS
S		1PC
T		1PC


STEP 11




A		8PCS
C		8PCS
Q		4PCS
T		1PC
V		16PCS

ASSEMBLY INSTRUCTIONS

STEP 12




STEP 13




ASSEMBLY INSTRUCTIONS

STEP 14



P		8PCS
---	--	------


STEP 15



A		2PCS
B		2PCS
C		2PCS
S		1PC


ASSEMBLY INSTRUCTIONS

STEP 16



C		4PCS
F		6PCS
G		6PCS
H		6PCS
T		1PC


STEP 17



A		8PCS
B		8PCS
C		8PCS
S		1PC


ASSEMBLY INSTRUCTIONS

STEP 18




D2		6PCS
E		18PCS

STEP 19




A		12PCS
---	---	-------

STEP 20



I		8PCS
---	--	------


STEP 21



I		4PCS
---	---	------


ASSEMBLY INSTRUCTIONS

STEP 22




B		8PCS
---	--	------

STEP 23




B		4PCS
---	--	------

STEP 24



J		2PCS
K		4PCS


STEP 25




J		1PC
K		2PCS

ASSEMBLY INSTRUCTIONS

STEP 26






STEP 27



O 12PCS


STEP 28




J		4PCS	L		8PCS
K		8PCS	M		48PCS

ASSEMBLY INSTRUCTIONS

STEP 29




STEP 30




ASSEMBLY INSTRUCTIONS

Finish!




HINGE ADJUSTMENTS




① Sideways / Tilt adjustment

Turn the screw
clockwise to move the door further away from
the side of the cabinet
anticlockwise to move the door closer to the
side of the cabinet



② ④ Height adjustment

While supporting the weight of the door, turn the
screws
clockwise to move the door up
anticlockwise to move the door down



③ Forward and back adjustment

If the gap between the back of the door and the
cabinet is too small, and the door may not close
fully. Turn the screw
clockwise to decrease the gap between the
door and the cabinet
anticlockwise to increase the gap between the
door and the cabinet

