

ASSEMBLY INSTRUCTIONS

1. Place all parts on a flat smooth surface.
2. Connect the (B Tube) to the (A Base).
3. Connect top part (C Lamp-cap) to the (B Tube).
4. Install the (D Glass shade) on the Socket and put the (E Rubber pad) on, then secure with the (F Socket ring)
(Socket Ring located on socket)
5. Turn the **Universal Joint** and make the lamp shade to a correct position.
6. Install (G Bulb) (Not included)



CAUTION - Refer to the wattage caution label located near the lamp holder for maximum wattage - do not exceed the maximum wattage.



WARNING - Do not attempt to replace the bulb(s) while the lamp is plugged into a wall receptacle

CARE INSTRUCTIONS - Use only a soft cloth; do not use any chemicals or abrasive cleaners.

IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit it, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

E26 Type A.40W X 1 (Not included)

E26 CFL 13W X 1 (Not included)



