



Assembly Instructions




Landon-24




Landon-30


Parts List



A x1



B x1



C x4

Hardware



(H1) x 8



(H2) x 8




(H3) x 8



(H4) x 1


Assembly Instructions

Step 1




Assembly Instructions

To adjust the door:




Adjust laterally




Adjust depth

To remove or install the hinges:



Remove



Install