


Outdoor Fire Table

If you have any questions about the product, please feel free to contact us.

E-Mail: Patiofurnitureserviceteam@outlook.com



After-sales mailbox:

Patiofurnitureserviceteam@outlook.com

NOTICE



Please retain these instructions for future reference.

Dear Customer

● Thank you for your purchase. When you receive the product, please make sure that all the parts are intact. If any parts are missing, please contact us promptly to request replacement parts.

● Then follow the entire installation instructions to install.

● Each part is crucial, so please be careful not to lose any. It is recommended to store parts with different lettered identifiers in separate boxes or bags to avoid confusion during installation.

A . The outer box is damaged

B . The product is damaged / bent / cracked while you open the box

C . The parts / accessories / assembly tools are missing

D . The instructions are not clear and can not be referred

E . The product has functional problems



F . Other aspects that you are not satisfied with

Please feel free to contact us for help, and provide the following information:











Platform/Shop name/Order ID/buyer's name/ receiver's address/Problem description.

(Homefurnitureserviceteam@outlook.com) will reply within 24 hours and will do our best to resolve the problem for you.

HARDWARE LIST


①  M6x15 12 pc	②  M6x30 4 pc	③  M6x35 5 pc	④  Φ6x12 21 pc	⑤  Φ6.5x14x3 1 pc
⑥a  Hex Wrench 1 pc				

PART LIST

				
1 pc	1 pc	1 pc	1 pc	1 pc
				
1 pc	1 pc	1 pc	1 pc	1 pc
				
1 pc				

1. Please ensure that all accessories are complete before starting the installation.
 2. Due to the variety of accessories, many accessories may be glued together, please check carefully
 3. If any accessories are missing or damaged, please contact the seller immediately.
- E-Mail: Patiofurniture Serviceteam@outlook.com


STEP 1 Frame Structure



C 1 pc	D 1 pc	E 1 pc	3 4 pc
4 4 pc	6a 1 pc		


STEP 2


Determine the component installation direction based on the positions of holes.




Ⓒ 1 pc	Ⓗ 1 pc	① 8 pc	④ 8 pc
Ⓐ 1 pc			



STEP 3




Ⓕ  1 pc	Ⓒ  1 pc	Ⓓ  1 pc	Ⓔ  1 pc
Ⓖa  1 pc			




STEP 4





A 	1 	4 	6a 
1 pc	4 pc	4 pc	1 pc

STEP 5




① 	② 	④ 	⑥a 
1 pc	4 pc	4 pc	1 pc

STEP 6




STEP 7

Place a glass cover and cover it with a waterproof cover. There are gaps on both sides of the waterproof cover for ventilation




STEP 8



STEP 9

LIGHTING INSTRUCTIONS:

1. Read instructions before lighting;
2. Push and turn the knob to LOW;
3. Hold igniter to light the burner,
release control knob after 15 seconds;
if burner does not light, wait 5 minutes, repeat;
4. Adjust flame to desired flame with the control knob.




Electronic
Ignition



+ AAA
Unscrew Button
Insert Battery

LOW

OFF



HI

AFTER-SALE SERVICE CARD

If you have any suggestions for our products or find that the products have quality problems, please contact us first, our after-sales team will reply you within 24 hours, and we will do our best to give you solutions until you are satisfied.

Guaranteed Customer Service

Your shopping experience is very important to us!
Feel unsatisfied? **Contact us!**
Have any questions? **Contact us!**

Wanna Share how wonderful our smart products makes your home?
Share your pictures with us.
Any suggestions? **Contact us!**
We gotcha back!

✉ Patiofurniture Serviceteam@outlook.com

