

## INSTALLATION INSTRUCTION





Notes:Don't tighten screws completely at first, just in case parts were assembled wrong and need disassembled. Tighten screws at last when all parts are put together.




No.	PICTURE	SIZE	QTY
A	(1) (1) (1) (1) (1) (1) (1) (1) (1) (1)	M6*10	8
В	(M))))))))))	M6*30	20
С	(M))))))))))))	M6*35	17
D		ST7*40	4
Е		M6*35	8

No.	PICTURE	SIZE	QTY
F	0===		4
G	٠	М6	9
	<u>~</u> 8		1
			1







## INSTALLATION INSTRUCTION STEP 7 M6 $\bigcirc$ 10 🛦 G G d G G 🛔 G 🛔 G G J G ∄ G G **७** M6 Х9 STEP 8 (10)M6\*35 **()** X2 STEP 9 В В M6\*30 (a)))))))))))) Х8 С M6\*35**(a)** X4 5

## INSTALLATION INSTRUCTION STEP 10 С С M6\*35(a) X7 STEP 11 С C C M6\*35 (0)))))))))))) Х4 X1 STEP 12 We genuinely appreciate your purchase of our product. Any problem(installation or damage caused by shipping),please feel free to contact us. Our customer service will help to solve the problem for your ASAP, as your satisfaction is our final goal. M6\*30 В

**()** 

X8