

Assembly Instructions


Caution : You must read this before you proceed.

Care & Maintenance




- ⊘  • Not for commercial use. For residential use only.
- ✓  • Furniture may scratch floors. We recommend using furniture pads to protect your floors.
- ⊘  • Do not put hot items directly on furniture surface.
- ⊘  • Do not clean furniture with harsh cleansers or polish.
- ⊘  • Do not place furniture under direct sunlight.
- ⊘  • Do not place furniture near heating or cooling vents.
- ⊘  • Do not write on furniture without a padded harrier to protect the surface.
- ⊘  • Do not place furniture outside. For indoor use only.
- ⊘  • Stains may be removed with mild soap solution and damp cloth.
- ⊘  • Children should not climb or jump on the furniture.
- ✓  • Dust and pick-up spills using a clean, non-colored, lint-free cloth.

Please look in carton for hardware pack.


DINING CHAIR




PART LIST

LABEL	PICTURE	DESCRIPTION	QTY
①		Backrest Frame	1
②		Seat Frame with Cushion	1
③		Front Legs	2


HARDWARE

LABEL	PICTURE	DESCRIPTION	QTY
Ⓐ		Bolt (M6*Ø13x75mm)	4
Ⓑ		Bolt (M6*Ø13x40mm)	6
Ⓒ		Washer	10
Ⓓ		Spring Washer	10
Ⓔ		Allen Wrench	1


Step 1:




Step 2:



Step 3:



Step 3:



Assembly is complete.