






Instruction Manual



PARTS LIST

A: Seat cushion	B: Gas lift cylinder
1 PC	1 PC
	
C:Base	D: Rolling wheel
1 PC	5 PC
	

INSTALLATION

