

VIVOHOME

THANK YOU!

NOTE:

To continuously improve its products, VIVOHOME reserves the right to modify this information without prior notification.

For any questions regarding assembly, please watch the video on the product page or contact our customer service. Our customer service will gladly assist you with any additional questions, comments, or concerns.

Thank you for using VIVOHOME products in your home!

Thank You for Purchasing from


VIVOHOME

Made in China

VIVOHOME

HOW-TO

USER MANUAL



**Casual Canopy Collection-8x8ft
Central Lock Slant Leg Canopy**

CONTENTS

Warnings & Maintenance	1
Parts List and Diagram	2
Assembly Steps	3
Take Down The Canopy	8
Warranty	11

- Improper cleaning or maintenance.
- Damage caused by any reason other than the intended use of the product.
- Indirect loss or damage caused by the product.

HOW TO MAKE A WARRANTY CLAIM

If you find any defects that affect the use of the product or if the product stops working and cannot be repaired during the warranty period, please contact our customer service team at our email or via Amazon & app's direct messaging service as soon as possible. Provide the following information to expedite the process:

- Order number
- Images and/or videos illustrating the issue
- A detailed description of the problem

VIVOHOME will provide technical support, replacement, refund, or other solutions based on the nature of the issue. If you wish to return the original package for any reason, please contact us for confirmation before proceeding. You can expect to receive a response within 48 hours.

Thank you for choosing VIVOHOME. We are committed to ensuring the quality and satisfaction of your purchase. If you have any questions or need assistance, please do not hesitate to contact our customer service team.

SECTION A

Warnings & Maintenance



THIS ITEM IS NOT INTENDED FOR USE AS A PERMANENT STRUCTURE.

This canopy has been developed and is intended to provide protection from the sun. DO NOT use any gas or flame sources under or near this product. Excess water buildup can cause the frame system to become unstable and collapse, possibly causing injury. Any personal accessories or modifications to the product should be removed before the onset of inclement weather, such as heavy rain, wind, lightning, hail, snow, etc.




This product should be properly taken down to avoid permanent damage to product components and any possibility of personal injury. This product is not a toy and is not designed for use by children. Under no circumstances should this product be used as a permanent or temporary storage facility for children's toys, garden tools, personal belongings, or similar valuables.

CARE AND MAINTENANCE

For long-lasting durability and the best possible protection for your canopy, follow these care and maintenance instructions: Your product is NOT machine washable or dryable. Use mild soap (not detergent) and plenty of water to clean the top. Let the fabric and frame dry completely to avoid mildew before closing and storing. The frame will operate and look better if occasionally wiped with silicone spray, especially before and after use in damp conditions. Remove excess silicone residue before applying top. Use a seam sealer if the top leaks or drips water, which is available at most sporting goods and hardware stores. Slightly tighten the bolts if the frame becomes loose.

Parts List and Diagram



Item No.	Reference Image	Qty.
A	 Canopy Frame	x1
C	 Stake	x8
E	 Rope	x4

Warranty



The VIVOHOME warranty program is our commitment to you. We are committed to providing you with a high-quality product that meets your needs and expectations. To demonstrate our confidence in the durability and performance of our products, we offer the following warranty.

WARRANTY COVERAGE

This warranty program applies to any orders, purchases, receipts, or use of any products sold by VIVOHOME and is valid for a period of 1 year from the date of purchase. However, please note that this warranty period is only valid for the original order. If you receive a replacement order during the warranty period, it will not include a separate warranty period.

WARRANTY EXCLUSIONS

This warranty does not cover damage resulting from misuse, accident, unauthorized modification, or any other circumstances not directly related to the manufacturing and design of the product, including but not limited to:

- Parts lost during use.
- Normal wear and tear of products or parts.
- Incorrect installation (such as using the wrong voltage) or assembly.
- Exceeding the bearing capacity of the product.
- Use under extremely harsh conditions.


Take Down The Canopy



STEP 3

Stow the frame and place it into the storage bag.

NOTE: Be careful to prevent your hands from pinching.




Assembly Steps



STEP 1


Pull up one section of the leg tube and open the frame.

NOTE: Be careful to prevent your hands from pinching.




**STEP 2**

Attach the canopy top.

**STEP 2**

Release the central lock and retract the leg tubes.




Take Down The Canopy



STEP 1

Remove the wind ropes and floor spikes.




Assembly Steps




STEP 3

Lock the frame.



**STEP 4**

Fully extend the leg tubes.

**STEP 5**

Install the wind ropes and floor spikes, and secure the enclosure fabric.

