

INSTALLATION INSTRUCTIONS

Waterfall Kitchen Sink Set



+44 7883 319408

English



Must-Read Pre-Installation Notes:

- **Inspect and Verify**

Check the product and all parts. Contact us if anything is missing or damaged.

- **Follow Local Codes**

Ensure installation meets local plumbing and building regulations.

- **Pressure and Temperature Limits**

Pressure: Max 0.5 MPa (5 bar). Use a pressure relief valve if exceeded.

Temperature: Max 60°C (140°F). Keep the faucet spray head away from heat sources.

- **Turn Off Water Supply**

Shut off hot and cold water to prevent leaks.

- **Flush Pipes and Clear Area**

Flush water pipes to remove debris and keep the area clean and spacious.

- **Countertop Strength**

Ensure the countertop can support the sink's weight.

- **Read the Manual**

Keep this manual for installation, maintenance, and cleaning guidance.

- **Use Proper Tools**

Prepare all necessary tools beforehand.

- **Hire a Professional**

A qualified installer should follow the steps in this manual.



**For any questions or concerns,
feel free to reach out to us:**

+44 7883 319408

INSTALLATION INSTRUCTIONS

Product Dimensions

Model No.	Length (mm)	Width (mm)	Height (mm)
EU1K0183	750	460	220
EU1K0185	800	460	220




Reference Cutout Dimensions

• Please Note:


All dimensions are manually measured and may have slight variations.
We recommend verifying the actual product dimensions upon receipt before cutting cabinets or proceeding with installation.

Model No.	Drop-in		
	Length (mm)	Width (mm)	Height (mm)
EU1K0183	720	430	220
EU1K0185	770	430	220



INSTALLATION INSTRUCTIONS


Product Accessories List



- **Please note:**

Some small parts and hoses are not fully displayed, and the product received shall prevail.

Recommended Tools




- **Sealant:** We recommend using silicone caulk specifically designed for stone and granite, or a general-purpose silicone sealant.
- **Note:** Installation tools are not included; please ensure you have them prepared.


INSTALLATION INSTRUCTIONS

Kitchen Sink Installation Instructions


This manual only illustrates the drop-in installation method.




(1) Place the sink upside down on the worktop in the desired position ensuring that the cabinet framework will clear all parts of the sink. Using a soft, sharp pencil, carefully trace around the sink as accurately as possible. Once traced, remove the sink.




(2) Draw a 15mm inward line inside the traced outline. This line marks the cutting boundary for creating the opening.



(3) Carefully cut along the marked cutting line using a suitable cutting tool. After cutting, smooth the edges of the cut with sandpaper to ensure a clean finish



(4) Fill any gaps between the sink and the countertop with clear silicone sealant, maintaining a width of 3.2–6.4mm for a secure seal.



(5) Slowly lower the sink, with the kitchen faucet already installed, back into place, ensuring it fits tightly against the countertop and covers the silicone sealant completely.



(6) After placing the sink, verify its alignment. Use silicone sealant or fasteners to secure the connection and prevent water leaks.

Note: Step images are for reference only and may not match the actual product.

INSTALLATION INSTRUCTIONS

Kitchen Sink Assembly Instructions


(1) Install the Pull-Out Faucet

Insert the faucet body through the designated mounting hole on the sink.



(2) Install the Gaskets and Mounting Hardware

As shown in the diagram, slide the rubber gasket, metal washer, and mounting nut onto the threaded shank from underneath the sink.




(3) Secure the Mounting Hardware with Screws

Use screws to tighten the mounting nut and securely fasten the faucet in place.



(4) Connect the Hot and Cold Water Lines

Connect the hot and cold water lines and the short hose according to the labels on the hoses and the markings next to the installation holes (H = hot water, C = cold water, Q = pull-out short hose).



Note: Accessory updates may cause slight appearance differences, but functionality is unaffected.

INSTALLATION INSTRUCTIONS


(5) Install the Counterweight

Attach the counterweight to the pull-out hose and secure it with screws.




(6) Connect the Water Hoses

As shown in the diagram, connect the pull-out faucet hose to the short hose.




(7) Install the Drinking Water Faucet

Insert the drinking water faucet into the mounting hole, then secure it from underneath the sink using the rubber gasket and mounting nut.



(8) Install the Soap Dispenser Set

Insert the soap dispenser pump into the designated hole on the sink and secure it from underneath using the gasket and mounting nut.




Note: Accessory updates may cause slight appearance differences, but functionality is unaffected.

INSTALLATION INSTRUCTIONS

(9) Install the Soap Dispenser Set

Screw the soap bottle onto the pump from below and make sure all parts are tightly connected.




(10) Install the Cup Rinser Set

Remove the metal washer and mounting nut pre-attached to the cup rinser.




(11) Install the Cup Rinser Set

Peel off the adhesive backing from the spacer ring and stick it to the bottom of the cup rinser.



(12) Install the Cup Rinser Set

Insert the cup rinser into the designated hole on the sink. From underneath, reattach the metal washer and mounting nut to secure it in place.




Note: Accessory updates may cause slight appearance differences, but functionality is unaffected.

INSTALLATION INSTRUCTIONS

(13) Install the Cup Rinser Set

Connect the water hose to the bottom of the cup rinser and ensure it is tightly fastened.



(14) Install the Basket Strainer

Place the white sealing ring over the drain opening, then insert the basket strainer and press down gently to ensure a proper fit.



(15) Install the Drain Housing

From underneath the sink, place the black sealing ring onto the basket strainer, then screw on the drain housing securely.



(16) Install the Drain Pipe

Install the drain pipe and ensure the blue sealing ring is placed correctly before tightening the connections.



Note: Accessory updates may cause slight appearance differences, but functionality is unaffected.

INSTALLATION INSTRUCTIONS

(17) Install the Anti-odor Cup

Screw the anti-odor cup onto the bottom of the drain pipe, making sure the blue sealing ring is properly in place.




(18) Install the Waste Pipe

Connect the waste pipe to the side of the anti-odor cup, making sure the blue sealing ring is in place, then tighten the connection.



(19) Install the Waste Pipe Connector

Insert the connector into the end of the waste pipe until it fits snugly.



(20) Install the Blue Gasket on the Overflow Pipe

Place the blue gasket onto the head of the side overflow pipe, ensuring it fits securely.



Note: Accessory updates may cause slight appearance differences, but functionality is unaffected.

INSTALLATION INSTRUCTIONS

(21) **Secure the Overflow Pipe Head**

Install the metal washer inside the sink at the overflow hole, secure the overflow pipe head with a screw, and attach the decorative cover.



Note: Accessory updates may cause slight appearance differences, but functionality is unaffected.

INSTALLATION INSTRUCTIONS

(22) Connect the Overflow Pipe

Attach the pipe to the overflow pipe head and the side inlet of the drain system.




(23) Install the Drain Cover

Place the drain cover over the drain opening.



(24) Install the T-Valve

Connect the T-valve to the cold water line, the cup rinser inlet hose, and the angle valve (not included) as shown.



Note: Accessory updates may cause slight appearance differences, but functionality is unaffected.

INSTALLATION INSTRUCTIONS

Use and Maintenance of the Sink:

1. When handling or installing the sink, take care to avoid collisions, which could lead to scratches or deformation of the sink.
2. Our sinks are made from high-quality stainless steel, providing excellent corrosion resistance. However, improper use or maintenance can result in surface rust or rust spots.
3. After kitchen renovations, promptly remove any residue such as welding debris, cement, oil, and other impurities from the sink to prevent rust and mildew.
4. In areas with poor water quality or where water contains high levels of iron and other metals (due to galvanized pipes), failing to clean water stains quickly may lead to floating rust on the sink's surface over time.
5. Rust spots can also develop when dust containing minerals or acidic/alkaline substances settles on the sink's surface, particularly in newly decorated homes exposed to moisture.
6. Prolonged exposure to chemical agents, cleaning products, paints, sauces, or oil residue can cause mold buildup on the sink's surface. Regular cleaning is essential to prevent this.

Prevention and Treatment of Sink Issues:

1. During kitchen renovations, it's recommended to install the sink last. Before installation, drain any residual water from the pipes to avoid contamination.
2. After installation, thoroughly rinse the sink to remove any debris or residues.
3. Clean the sink after each use to prevent dirt and water stains from accumulating.
4. Avoid leaving kitchen knives, bottle openers, or other items in the sink for long periods. Do not scrub the sink with a steel wire ball or cut items directly on its surface.
5. If rust or floating rust spots appear on the sink, apply toothpaste to the affected areas and scrub with a dishcloth until clean.

Faucet Cleaning Instructions:

To maintain the pristine condition of all processed surfaces, including faucets and their accessories, please follow these steps:


1. Clean the coated surface with neutral soapy water.
2. Wipe the entire surface thoroughly with a clean, soft cloth.
3. Avoid using harsh detergents, such as ammonia, dishwashing liquid, or toilet cleaners, as they may damage the plating.
4. Do not use abrasive cleaning tools or chemicals on the faucet and its accessories.

Faucet Maintenance:


1. Turn on the faucet and rub the nozzle to remove impurities.



2. If water flow is reduced due to impurities, remove the shower head aerator, clean any accumulated debris, and securely reinstall it.




Faucet Use Instructions




- Turn the knob to the right to get cold water from the waterfall faucet. Keep turning for mixed water, then hot water. Return the knob to the centre position to switch the water off.
- Turn the knob to the left to divert water through the pull-down faucet. Continue turning for cold, mixed, and hot water. Return the knob to the centre position to stop the flow.



To use the extender, simply pull the head and move it freely.



Press the button to switch to shower spray mode.



Press the button again to switch to aerated water mode.

NOTE: Illustrations may not exactly represent the contours of the product.

ONE YEAR LIMITED WARRANTY

LIMITED WARRANTY COVERAGE

1-YEAR LIMITED WARRANTY

This product is made from high-quality materials and is designed to provide long-lasting durability. If defects in materials or workmanship are found under normal use within the first year from the date of delivery, replacement parts will be provided at no charge, or, at the manufacturer's discretion, any defective product or part will be replaced, provided it has been installed, used, serviced, and maintained properly. This warranty applies only to the original purchaser, and proof of purchase is required for any claims. Scratches are not covered under this warranty.

The manufacturer warrants that this product will be free from manufacturing defects for the duration of the above-mentioned warranty period. Please retain a copy of the original invoice as proof of purchase.

The manufacturer will, at its discretion:

- (1) repair or replace the defective part(s) or product(s) free of charge;
- (2) issue a refund for the original purchase price (valid within 30 days of the delivery date); or
- (3) issue a credit towards a new product purchase. Shipping and delivery charges may apply and are at the manufacturer's discretion.

Installation by a licensed professional plumber is recommended. The manufacturer is not responsible for damage or failure resulting from improper installation, misuse, or failure to use a licensed professional. Additionally, the manufacturer is not responsible for any removal or installation costs.

This warranty does not cover products subjected to accidents, negligence, improper installation, abuse, misuse, or the use of abrasive cleaners, alcohol, or organic solvents. These exclusions apply regardless of whether the actions were performed by a contractor, service company, or the purchaser.

The manufacturer's responsibility under this limited warranty is limited solely to the replacement of parts and does not cover any other costs. The manufacturer is not responsible for labour charges, damage incurred during installation, repair, or replacement, nor for any indirect, incidental, or consequential damages, losses, injuries, or costs related to this product. Except as required by law, this limited warranty replaces and excludes all other warranties, whether express, implied, statutory, or otherwise, including but not limited to warranties of merchantability or fitness for a particular purpose.

RESPONSIBILITIES OF OTHERS

It is the responsibility of the installer or contractor acting on behalf of the user to inspect the unit before installation. They must ensure that the unit is free from defects or damage.

Notices are placed on the unit and packaging to inform the installer of this responsibility.

If a problem is found, the unit must not be installed. The manufacturer is not responsible for damage or failure that could have been identified, repaired, or prevented through proper inspection prior to installation.

Damage occurring during transit is the responsibility of the carrier. The user or installer must inspect the unit upon delivery. If damage is found, it must be reported immediately to both the seller and the carrier in writing, and an inspection must be requested. If the carrier does not respond, the issue should be reported to both parties. Freight claims should be filed promptly thereafter.

LIMITATIONS AND EXCLUSIONS

This warranty does not cover damages resulting from negligence, misuse, abuse, improper installation, accidents, hard water, mineral deposits, exposure to corrosive materials, misapplication, improper maintenance, product alteration, or failure to follow care and installation instructions. The warranty is void if the product is altered or if repairs are attempted with unauthorised accessories or parts not provided by the manufacturer.

The manufacturer is not liable for loss of use, inconvenience, or any incidental or consequential costs, expenses, or damages. Some states do not allow the exclusion or limitation of incidental damages.

DISCLAIMER

Except as expressly stated, no warranties or obligations, whether express, implied, oral, or statutory, are provided. No dealer or individual has the authority to make any warranties or representations regarding the manufacturer or its products. The manufacturer is not responsible for any unauthorised warranties or representations.

WARRANTY SERVICE

NOTE: When requesting warranty service, please provide the following:

- A copy of the original invoice
- Date of installation
- Description and photographs of the defect
- Model number or product description

To obtain warranty service or replacement parts, please contact Customer Service. The manufacturer will determine whether to repair or replace the product, issue a refund, or provide a credit.