


PURPLE LEAF

est. 2013



Outdoor Patio Chaise Lounge



ASSEMBLY AND OPERATION GUIDE

Warnings and Cautions

Please retain this instruction for future usage and read carefully before assembly.

Make sure you have all the parts & hardware as item list shows.

2 adults are recommended to install your chair.

Do not discard any of the packaging until you have checked that you have all the parts and pack of fittings.

Check all bolts for tightness before use, and periodically check and tighten bolts ensure your chair works properly.

Some parts might have sharp edges/corners. Please follow basic safety precautions to reduce the risk of hurts.

Notes

1. Please cover and store the product indoor if not in use.

2. Do not fully tighten the screws until finish each step of installation.


3. Ensure that use carpet for the installation for preventing scratches.

CHOKE HAZARD

THIS ITEM CONTAINS SMALL PARTS WHICH CAN BE SWALLOWED BY CHILDREN.

PLEASE KEEP IT AWAY FROM CHILDREN UNDER 3 YEARS OLD AND PETS DURING INSTALLATION.


Check List

Part No.	Image	QTY		Part No.	Image	QTY
A		1		I		1
B		1		J	 longer	1
C		1		K	 shorter	1
D		1		L	 1/4*15	16
E		1		M	 1/4*45	16
F		1		N		32
G		1		O		1
H		1				

Chair Assembly



C × 1 


D × 1 

E × 1 

F × 1 

L × 4 

N × 4 



STEP 1

Chair Assembly



G × 1





H × 1



M × 8



N × 8




STEP 2

Chair Assembly




A × 1



M × 1



N × 1



Please do not tighten the screw completely until **step 8**. And we recommend having one person hold the component while another aligns the screw hole.

STEP 3


Chair Assembly



M × 1



N × 1




STEP 4

Chair Assembly




B × 1



M × 3



N × 3



STEP 5


Chair Assembly



M×3



N×3



STEP 6

Chair Assembly




I × 1

L × 4

N × 4

The side with holes is facing to the ground.



STEP 7

Chair Assembly




J × 1 

K × 1 

L × 8 


N × 8 

The side with holes is facing to the ground.




Please fully tighten all screws after the screw of Part **J** and **K** is aligned.

STEP 8




Note


How to fix uneven chair.




If the chaise lounge is uneven after installation.




①



First place the problematic leg (off the ground) on something at least 10 inches high.



②



Then press down on both sides of the chaise lounge with your hands.

Warranty

Frames

Frames constructions are warranted to be free from defects in material and workmanship for 1 year from item purchased. Damage to frame from negligence won't be covered by this warranty.

Bolts & nuts

Bolts and nuts are warranted to be free from defects in material and workmanship for 1 year from item purchased. Damage from exposure to chemicals (including not only oils, spills, fluids) won't be covered by this warranty.

Fabric

Fabric is warranted to be free from defects in material and workmanship for 1 year from item purchased. Damage from exposure to chemicals (including but not only oils, spills, fluids) won't be covered by this warranty.

Warranty Limitation

This warranty is for the original purchase order only. (Order number required). This warranty is non-transferable. Purple Leaf is responsible for the free replacement part including shipping charges for the 1 year warranty.

Warranty Exclusion

This warranty does not cover products subject to negligence, abuse usage, inappropriate installation. Purple Leaf reserves the right to explain warranty exclusions. When the replacement item is applied, the 1 year warranty automatically expires. Please feel free to contact us for applying warranty.



Purple Leaf Inc.
15950 Boyle Avenue, Fontana
CA, 92337
chair@purpleleafgarden.com
©Copyright 2013-2025 Purple Leaf Inc.
All Rights Reserved.V.1