

Operation Instructions

1、 Operating instructions

1. When the Safe box is in the open door state, correctly install 4 No. 5 batteries and connect the circuit to work

2. Factory unified password '159'

3. Each press of the number beeps once, indicating that the input of the button is acknowledged.

Once entering sleep mode, all previous operations will be terminated, and pressing any key will wake up and enter the functional operation.

2、 Changing or setting personal password

1. When the door is open, press the red button on the inside of the door, the buzzer will sound twice, and the personal password will start to be set or changed.

2. Enter your proposed 3-8 digit personal password and press the '#' key to confirm. The buzzer will beep once and the green indicator light will light up once, it indicate that the personal password has been set or changed successfully; Setting errors should be accompanied by three short beeps and three flashing red lights.

3. For example, press the red button to enter 159 and press '#'

3、 Opening the door

1. Enter the correct personal password and press the '#' key to confirm. The buzzer beeps twice, the electromagnet closes for six seconds, and the green indicator light lights up to open the door. If the password input is incorrect, press the '#' key to confirm and the buzzer beeps three times. The red light flashes three times.

2. If the password is entered incorrectly three times in a row, it will be locked for 20 seconds, and if it is entered incorrectly six times in a row, it will be locked for 5 minutes. During the lock period, the red light turns on for 1 second every time the key is pressed, and then goes off

4、 Undervoltage indication

When the yellow and green lights on in the same time, it indicate that the battery is under voltage. Please replace the battery in time.