
5-Piece Wicker Sectional Sofa Set



The schematics in this manual are for assembly and operation illustration only. They may differ from the actual appearance.

General Guidelines

- Please read the following instructions carefully and use the product accordingly.
- Please keep this manual and hand it over when you transfer the product.
- This summary may not include every detail of all variations and considered steps. Please contact us when further information and help are needed.
- Any question, please contact our customer service.

Notes

- Personal injury and/or damage to the product may occur if products are used outside of their
 intended purposes and/or if products have been changed/modified from their original design. The
 product must be assembled and used in accordance with the provisions of the manual. The seller
 does not assume any responsibility or liability with respect to any damage caused by incorrect
 assembly or improper use.
- Carefully check accessories when opening the package. If anything is missing or damaged, please contact us immediately.
- Please do not force or over tighten the nuts. If a nut becomes stuck, unscrew it and start again.
- Keep in mind that not to tighten screw until you fully set up, After set up, fully tighten screws.
- Please keep all the packaging for the product until you are satisfied with your purchase as we cannot accept any returned item not in the original packaging.
- Please ensure that you have sufficient space and people to assemble the item.

Warnings

- Keep children away when assembling the product. Small parts are included in the package; they
 may be fatal if swallowed or inhaled.
- To avoid the potential dangers of suffocation, please keep all parts and packaging (film, plastic bags, foam, etc.) away from babies and children.

Daily Maintenance


- Sweep surfaces as needed using a soft-bristle brush.
- Store outdoor furniture indoors or cover well when not in use. Whether you live in a mild or harsh
 climate, using patio furniture covers will prolong the life of your furniture and keep it looking like
 new.
- To extend the life of your outdoor cushions and pads, clean them regularly. Store away when not
 in use, preferably in a cool, dry place indoors. Ensure the cushions are completely dry before
 storing.

DESCRIPTION: CORNER SEAT

Item no.	Reference Image	Description	Qty.
А		Arm Rest	1
В		Seat Back	1
C ₂		Seat Base	1
D		Side Panel	1
E		Ssat cushion	1
F		Back cushion	1


	5 (
Item	Reference	Description	Qty.
no.	Image	Description	Gty.
G		Armrest	4
G		cushion	1
Н		M6*30	9
		100 30	9
	~		4
l		M6*35	4
		\A/ I	40
J		Washer	13
K	//	Allen Key	1
		, won toy	•


Tips: Do not tighten all screws fully until the item is well assembled.




DESCRIPTION: CORNER SEAT










DESCRIPTION: CORNER SEAT

Item no.	Reference Image	Description	Qty.
Α		Arm Rest	1
В		Seat Back	1
C ₁		Seat Base	1
D		Side Panel	1
E		Ssat cushion	1
F		Back cushion	1


	Deference	<u> </u>	
Item	Reference	Description	Qty.
no.	Image	Boomption	Gty.
G		Armrest cushion	1
Н		M6*30	9
ı		M6*35	4
J	0	Washer	13
K		Allen Key	1

Tips: Do not tighten all screws fully until the item is well assembled.





DESCRIPTION: CORNER SEAT












DESCRIPTION: ARMLESS CHAIR

Item no.	Reference Image	Description	Qty.
L		Seat Back	1
C ₃		Seat Base	1
D		Side Panel	2
E		Ssat cushion	1
F		Back cushion	1


Item no.	Reference Image	Description	Qty.
Н		M6*30	8
ı		M6*35	2
J	0	Washer	10
K		Allen Key	1


Tips:
Do not tighten all screws fully until the item is well assembled.



DESCRIPTION: ARMLESS CHAIR

STEP 3






DESCRIPTION: OTTOMAN

Item no.	Reference Image	Description	Qty.
М		Side Panel	2
N		Front & Back Panel	2
0		Table Top	1
Р		Ssat cushion	1


Item no.	Reference Image	Description	Qty.
Н		M6*30	12
J	0	Washer	12
K		Allen Key	1


Tips:
Do not tighten all screws fully until the item is well assembled.



DESCRIPTION: OTTOMAN

STEP 3






DESCRIPTION: COFFEE TABLE

Item no.	Reference Image	Description	Qty.
Q		Side Panel	2
R		Front & Back Panel	2
S		Table Top	1
Т		Glass Top	1


Item no.	Reference Image	Description	Qty.
Н		M6*30	12
J	0	Washer	12
K		Allen Key	1


Tips:
Do not tighten all screws fully until the item is well assembled.



DESCRIPTION: COFFEE TABLE


STEP 3





DESCRIPTION: 5-PIECE WICKER SECTIONAL SOFA SET

IteQ RS.	RefereRce IQage	DescriptiSR	Qty.
U		Plastic Clip	6



After finishing all assembling, please use plastic clips to connect each sofa.