YSCS01

Yellowstone Cooking Stove

Designed to burn kindling, small wooden sticks, and even lump charcoal.

854318 rev A

Save These Instructions In A Safe Place For Future Reference.

SAFETY NOTICE: If this stove is not properly used, a house or forest fire may result. For your safety, follow the installation instructions. Contact local building or fire officials about permits, restrictions and installation requirements in your area. NEVER OPERATE THIS PRODUCT WHILE UNATTENDED.


CAUTION! Please read this entire manual before you use your stove. Failure to follow instructions may result in property damage, bodily injury, or even death. Improper Use Will Void Your Warranty!

OPERATING SAFETY PRECAUTIONS

HOT WHILE IN OPERATION. KEEP CHILDREN, CLOTHING, AND FURNITURE AWAY. CONTACT MAY CAUSE SKIN BURNS. DO NOT TOUCH THE APPLIANCE UNTIL IT HAS COOLED.

WARNING: EXPLOSION HAZARD

NEVER USE CHEMICALS, GASOLINE, GASOLINE-TYPE LANTERN FUEL, KEROSENE, CHARCOAL LIGHTER FLUID, OR SIMILAR FLAMMABLE LIQUIDS TO START OR “FRESHEN UP” A FIRE IN THE APPLIANCE.



California Proposition 65 Warning

This product can expose you to chemicals including carbon monoxide, which is known to the State of California to cause cancer, birth defects, and/or other reproductive harm. For more information, go to www.P65warnings.ca.gov

OPERATING SAFETY PRECAUTIONS

1. Do not use this stove until you have read the operating instructions and user warnings.
2. Serious injury, death, and/or property damage may occur if the above instructions are not followed.
3. Use only on non-combustible surfaces. Do not use on a deck.
4. For outdoor use only and should not be used in a building, a garage, or any other enclosed area.
5. Do not use in an area with heavy grass, leaves, or other combustibles.
6. Extremely hot when in use. Never attempt to touch or move the firepit during use or before it has completely cooled down.
7. Do not use the stove for indoor heating. Toxic carbon monoxide can accumulate and cause asphyxiation and possibly death.
8. Not for commercial use.
9. This stove is not to be operated by children; this stove is not a toy.
10. Never leave the stove unattended, especially when children and pets are nearby.
11. This stove is not to be used in a boat or recreational vehicle.
12. Always use this stove in accordance with all applicable local, state, and national codes. Contact your local fire department for details.
13. Always check for local fire restrictions or bans before use.
14. When using the stove, exercise the same precautions you would with any open fire.
15. The use of alcohol, prescription or non-prescription drugs may impair the consumer's ability to operate the stove safely.
16. The stove is designed for use with natural wood and may not function properly with other fuel sources.
17. Do not store or use LP gas cylinders within 30 feet of the stove while it is in operation.
18. Do not use this stove near automobiles, trucks, vans, or recreational vehicles.
19. Do not use this stove under any overhead or near any unprotected combustible constructions. Avoid using under or near any overhanging trees or shrubs.
20. Do not wear flammable or loose clothing when operating the stove.
21. Do not use the stove in windy conditions.
22. Keep all electrical cords away from the stove.
23. All surfaces of this stove are extremely hot when in operation. To avoid burns and serious injury, do not touch the stove until the fire is completely out and it has completely cooled. Never touch the coals or ash to see if they're still warm.
24. Do not attempt to move or store this stove until all fire, coals, and ashes are completely extinguished and the unit has completely cooled.
25. Do not remove any coals or ash or clean the stove until the coals and ash are completely extinguished and the unit has completely cooled.
26. Do not lean over the stove when lighting or when it is in use.
27. Avoid breathing smoke from the fire and avoid getting smoke in your eyes.
28. The stove should be inspected and cleaned regularly after each use.

29. After a period of non-use, check the stove for signs of damage and creosote buildup. Do not operate until necessary repairs and/or cleanup is done.
30. Do not use water to extinguish the fire in the firepit.

DO NOT BURN

Waste and other flammable materials should not be burned in your stove. Burning these materials may result in the release of toxic fumes or render the heater ineffective and cause smoke.

DO NOT BURN:

- Garbage;
- Lawn clippings or yard waste;
- Materials containing rubber, including tires;
- Materials containing plastic;
- Waste petroleum products, paints or paint thinners, or asphalt products;
- Materials containing asbestos;
- Construction or demolition debris;
- Railroad ties or pressure-treated wood;
- Manure or animal remains;
- Saltwater driftwood or other previously salt water-saturated materials;
- Unseasoned wood; or
- Paper products, cardboard, plywood, or particleboard. (The prohibition against burning these materials does not prohibit the use of fire starters made from paper, cardboard, sawdust, wax, and similar substances to start a fire in an affected wood heater.)


ASHES

Empty ashes in an area free of any combustibles then drown the ashes with water. Next, mix the ashes and embers and scrape all partially burned wood to make sure all the hot embers are off them. Stir the embers after they are covered with water and make sure that everything is wet. Feel for heat left in coals, embers, and any partially burned wood. Once you think you are done, take an extra minute and add more water. Check the entire area possible sparks or embers. If it is too hot to touch, it is too hot to leave.


Instruction

Use in a well-ventilated area


How to Light




Place the fuel shelf into the installation sockets



Light up the stove with kindling




Feed larger pieces of wood into the door




3-4 sticks=High heat

Maintenance




Empty the ashes after each use



Wipe the outside of the stove



Overload will cause smoke and don't touch when it's hot.



Don't pour liquids into the stove.