
YEFU

YEFU

SINCE 2012

FOREST PROTECTOR




Outdoor Lounge Chair

! NOTE:
Please read the instructions below for reference


- Please do not exceed the weight limit for this item!!!
- Children need to be used under adult supervision.
- Do not sit on the armrests or use any part as a footstool or ladder.
- Please tighten all bolts, screws and knobs firmly before use to ensure they are secure, and check them regularly during use.
- If any parts are missing, damaged or worn, stop using the product and contact a professional for repair or replacement with genuine parts.
- Do not use this item in a way inconsistent with the manufacturer' sinstructions, as this will void the product warranty.
- Do not store this item near open fames or flammable chemicals.
- Please keep this item away from bug repellent, weed spray, sunscreen, lipstick or any other chemicals. This item's material will react with these chemicals, which will make it discolored.
- For surface scratch treatment, use a blade to gently scrape along the grain until the scratch fades. Then, follow up with 80-grit sandpaper or steel wool to smooth the surface. After treating the scratch, wipe away any remaining dust or debris.

STEP9


Adjust the support plate to change different angles.



STEP7



STEP8



Product Warranty Information.

All items can be returned for any reason within 30 days of receipt and will receive a fullrefund as long as the altered item is returned in its original product packaging and includes all accessories from its original shipment.Once the product has been received by YEFU the refund will be processed within 3 business days.







All returns must be shipped back to the YEFU warehouse or Amazon warehouse at custome expense. If the reason for return is a result of an error by YEFU warehouse or Amazonwarehouse, it will prepare a pre-paid shipping label.
Some returns may require pictures to ensure items are not damaged prior to return. Returned items are not considered undamaged until they have been received and verifiedby YEFU. All items damaged are the responsibility of the customer until the product isreceived by YEFU and verified to be in good condition.

All products have a 2-year warranty, during which we will provide free spare parts if anyparts are damaged (but you need to bear reasonable shipping costs)


⚠ WARNING

In no event shall any liability be assumed for direct, indirect or incidental personal injury, property damage or loss resulting from incorrect accessories, misuse, inadequate maintenance, unapproved modifications or negligence on this product.


In order to avoid the chair shaking make sure that the screws are tightened fully after all steps

A	1PC	B	1PC
			
C	1PC	D	1PC
			
E	1PC	F	1PC
			
G	2PCS	H	2PCS
			


STEP6












Rotate the buckle to put down the support plate




STEP5






I 1PC	J 2PCS
	
K 2PCS	L 1PC
	
M 1PC	AA 4PCS
	 M6*15
BB 4PCS	CC 16PCS
 M6*35	 M6*40
DD 2PCS	TOOLS
 M10*60	 M5 + M6

STEP1




STEP2


The grooved side of E and F face toward the outside.



STEP3



STEP4



install the cover after tighten the screw.