


INSTRUCTION MANUAL



Outdoor Sectional Furniture

ASSEMBLY INSTRUCTIONS



- Carefully unpack all the components and verify that all the necessary parts are included as listed in the packaging.
- Identify each component and refer to the step-by-step instructions.
- Assemble the furniture in the order specified to ensure proper alignment and fit.
- Use the provided tools or recommended tools for assembly. Do not use excessive force when tightening screws or bolts.
- If any difficulties arise during assembly, contact our customer support.

TOOLS REQUIRED



SMALL
WRENCH



ALLEN WRENCH
(PROVIDED)




SMALL
WRENCH





ALLEN WRENCH
(PROVIDED)

HARDWARE




PARTS




PRODUCT ASSEMBLY




1. Open the ottoman to access the sofa legs.



2. Install the legs using the provided washers.



4. Attach the ottoman to your sectional sofa for integrated placement.



MAINTENANCE AND CARE



Cleaning: Use a damp cloth to remove dust and dirt from the sofa surface. Apply a care agent (without wax) for protection.

Prevent Damage: Avoid sharp objects that can scratch the leather.

Stain Handling: Prevent oil and ink stains. Use a leather cleaner or a cloth with alcohol for cleaning.

Regular Care: Wipe with a damp cloth daily. Deep clean with leather cleaner every 2-3 months.

Prolong Lifespan: Discourage rough play and sweat contact. Allow ventilation with a 5-10 cm gap.

Sunlight Consideration: Avoid direct sunlight. Rearrange occasionally to prevent color differences.

Humid Areas: Expose to weak sunlight for an hour daily for seven days, every three months.

WARRANTY INFORMATION



Warranty Coverage: Our warranty provides protection against manufacturing defects in materials and workmanship for a specified period from the date of purchase, as outlined in the accompanying warranty documentation.

Exclusions: The warranty does not cover damages resulting from misuse, negligence, accidents, normal wear and tear, unauthorized repairs or modifications, improper assembly, or failure to adhere to the care and maintenance guidelines provided.

WARRANTY CLAIM PROCESS

To initiate a return on Amazon, please follow these steps:

1. Log into your Amazon account and go to the "Your Orders" section.
2. Locate the order containing the item you wish to return.
3. Contact our customer service for assistance in obtaining a prepaid return label.
4. Once you receive the return label, securely affix it to the package.
5. You can then choose to drop off the package at a designated carrier location or arrange for a pickup.
6. After we receive and inspect the returned product, we will initiate the refund process.
7. The refund will be credited back to the original payment method used during the purchase.
8. Typically, refunds are processed within 3-5 business days.