





ENCLO

HIDE IT WITH STYLE

Box Contents






EC18030

BOX CONTENTS

A Post (2) 1½" x 2⅜" x 72"		
B Slat (25) ⅝" x 2" x 34¼"		
C Rail (2) 1¼" x 2" x 34¼"	D Feet (2) 1" x 2" x 25"	
E Joiner Bracket (2) 		
F M5*50mm Wood Screw (10) 	G M6*30mm Bolt (4) 	H M6*80mm Bolt (4) 
I Nut (4) 	J Washer (12) 	K Lock Washer (8) 
		L Wrench (2) 

TOOLS AND OPTIONAL HARDWARE

NOT INCLUDED

 FREESTANDING  Power Drill  Phillips Bit <i>Freestanding configuration is only recommended for environments with low wind exposure.</i>	 DECK MOUNT  Power Drill  Wood Drill Bit  1/4" Lag Screws 3" Length (4)  Matching Driver Bit	 PATIO MOUNT  Hammer Drill  Concrete Drill Bit  Hammer  1/4" Concrete Wedge Anchor 2 1/4" Length (4)  Matching Wrench
--	---	--