










PARTS LIST

| Part No. | Description | Part picture | Qty | Part No. | Description | Part Picture | Qty. |
|----------|-------------|---|-----|----------|------------------|---|------|
| ① | Table Top |  | 1 | A | M8 Nut |  | 12 |
| ② | Table Leg |  | 4 | B | M8 Spring washer |  | 12 |
| ③ | Leg Support |  | 4 | C | M8 Flat washer |  | 12 |
| ④ | Wrench |  | 1 | D | M8 protect hats |  | 12 |

INSTRUCTIONS

Step 1




Place all parts on a flat and soft surface

Step 2



Turn over the table top. Take off the protect hat on the Stud. Then, Attach table Legs (2) to the Studs on the Table Top (1) using Washers and Nuts (A, B, C). DO NOT over tighten

Step 3



Attach the Table legs Support (3) to the four Legs (2) using flat washer, spring washer and nuts (A, B, C) DO NOT over tighten.

Step 4



Tighten all Nuts with wrench. Turn over the table. Adjust the pre-installed Rubber Pad (L) until the Table is level with the ground, Tighten all the nuts and cover them with nut caps (D). Your table can be used now.