




## ADAPT™ ADJUSTABLE WREATH HANGER INSTRUCTIONS



Press button.



Pull end down while button is pressed. Adjust to desired length and release button.



Wreath hanger slide mechanism too tight or too loose? Here's how to adjust it.

**For questions or concerns please contact us directly at [customerservice@haute-decor.com](mailto:customerservice@haute-decor.com).**

HD

HAUTE DECOR  
P.O. Box 1594  
Allen, TX 75013

MADE IN CHINA

♻️ please recycle

© 2019 Haute Decor