


# Installation instructions

## 1 Timing adjustment



## 2 Clean Surface




Option

it can cut according to the length which you need



## 3 Connect components



## 4 Choose the Sensor installation position

