


ASSEMBLY INSTRUCTION



NOTES:


























- The item is only intended to be used indoors. The product must be assembled and used in accordance with the provisions of the manual.
- It is recommended that assembly is undertaken by about 2 adults. Please read assembly instructions before assembly and strictly adhere to each step outlined. Estimated assembly time is 30 minutes.

WARNING:


- **WARNING FOR YOUNG CHILDREN** - This product contains small components, please ensure that they are kept away from small children while assembling.

1

PARTS LIST


A	B		C	O		P	Q		R		
											
2PCS	1PCS		1PCS	1PCS		4PCS	6PCS		2PCS		
S		T	U	V	W	X	a	c	d	e	f
											
2PCS		2PCS	2PCS	2PCS	4PCS	1PCS	1/4*85 4PCS	1/4*45 4PCS	1/4*37 2PCS	1/4*30 8PCS	1/4*21 4PCS
g	t	u	v	w	x	y					
											
1/4*19 8PCS	4PCS	1/4 4PCS	1/4 8PCS	1/4 2PCS	1/4 2PCS	1PCS					

NOTE: PLEASE DO NOT TIGHTEN THE BOLTS UNTIL ALL FIXED




3


③




④




⑤




⑥




7




8



9



10



Warranty Information:

We warranty this product to be free from defects in materials. This warranty covers five years from the date of original purchase.