


ASSEMBLY INSTRUCTION

DESCRIPTION: LIFT TOP WRITING DESK

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all parts and compare with the parts list below.

COMPLETED:




PARTS LIST

NO	DRAWING	DESCRIPTION	Q'TY
1		Table Top	1
2		Bottom Panel	1
3		Side Frame	2


HARDWARE LIST 1

NO	DRAWING	DESCRIPTION	Q'TY
A		Bolt Ø1/4-20*38(L)	12
B		Flat Washer Ø1/4"*Ø16*2mm	12
C		Spring Washer Ø1/4"*Ø13mm	12
D		Allen key M4	1
E		Tipping Restraint	1

STEP 1




STEP 2



HOW TO REMOVE DRAWER

To remove drawer, simultaneously pull tab up on one side and push down on the other and remove drawer.

Push tab down to remove drawer



Push tab up to remove drawer

