

一、PRODUCTS DESCRIPTION

The product is a new practical electric roaster. It is applicable to make any baked food. The baked food is brightly colored, flavored and sanitary. It will be much easier and faster to heat the food by this roaster. It takes the advantage of electrical switch; for this, it is easy and safe to operate. The whole roaster is beautiful in contour, delicate in workmanship, sanitary and environment-friendly. It is suitable for family, supermarket, leisure snack bars and places with large flow of people.

二、ADVANTAGES

- ☆ science of design,easy to operate
- ☆ Reasonable structure, safe and reliable
- ☆ environmental protection, time-saving, energy saving;
- ☆ Small and exquisite, suitable for various occasions.

三、PRODUCT PERFORMACE


According to the national standard and relevant provisions, we develop a new generation safe commercial BBQ grills. This product uses electric heating, and electrical standards in strict accordance with the requirements of circuit design, circuit safety grounding, and an external fuse and leakage protector, so as to ensure the safe of using the product.

Electric BBQ GRILLS working principle: this product uses the basic principle of electrical energy into heat energy, with ingenious structural design. Through the characteristics of the electric heating tube, converts electrical energy efficiency and environmental protection to heat source, baked out of all kinds of delicious food.

SIZE AND PARAMETERS

Model	Size (mm)	Volts (v)	Power (kw)
SC-JHD9-T	540*280*120	110-220V/50-60Hz	2.5
SC-JHD9-P	685*485*155	110-220V/50-600Hz	4

Circuit diagram



Special tips:

- 1.If a power supply cord is damaged, to avoid danger, its change must take by the manufacturer or its maintenance department or similar professionals.
- 2.Being flexible cable should be oil resistant sheathed cable (specify brand BC245 57)
- 3.Being the nominal cross-sectional area of soft wire of power should not be less than the copper wire 25mm²
- 4.The connection of the appliance being fixed lines must be equipped with a point at least 3 mm from the disconnecting device.
- 5.Being near the power connection virtual install earth leakage protection relay protection rating of 30 mA.
- 6.Do not use water to spray.
- 7.Do not let water being immersed.

四、OPERATION

This product use method is simple and convenient, users only need to put assembled BBQ GRILL to smooth place, After an external fuse and leakage protection device, then link to a 220V/ 50Hz AC power,It can be carried on barbecuing.

Steps:

1. Before using, the machine must be placed smoothly,and not allowed to pile up sundry around.
- 2.Before using, you must check whether the power supply is consistent with nameplate requirement, and power plug must be grounded.
- 3.After an external fuse and leakage protection device, then link to the near suitable power source.
- 4.The heat pipe are separately control, work independently, Humanized design,according to the needs of your barbecue,Can select two heat pipe at the same time or one of the heat pipe.

5.Finishing grill,please cut off the power and wait for the burners to cool to room temperature, clean up slag pulp tray, Oil residue, food debris , and then use wet dishcloth to clean barbecue net, heat pipe, and anything else that is stained with oil .

6.If don't use to BBQ GRILLS long time, please cut off the power, keep machine body clean.And put it in a wind, cool, dry place.

五. ATTENTION

1.Take care during transportation, to avoid damage, don't be inverted, stress, violent vibration.

2.Put the BBQ grill power in open air, and place in ventilated, dry, non-corrosive gas ,To avoid accidents for wire being affected with damp and damaged.

3. when clean and maintain, in order to avoid leakage,please cut off power.

4.DO not use too Wet dishcloth to clean, avoid electrical parts being a short-circuit; if wet, it must be dry then can continue to use.

5.When BBQ grill is heating or still in the high temperature; Please be careful of operation, in order to avoid scald, can't let children touch.

六. CAUTIONS

Be cautious during the transportation. Never place the machine up side down, or with heavy things on, or violent shaking or the roaster may be damaged.

Method

Electric BBQ grills basic faults and elimination method			
1	problem	Cause	Method
2	The heating switch is abnormal	Damage or loose circuit switch	Please ask professional maintenance or (back to the factory maintenance)
3	heat pipe can not reach the rated temperature	heat pipe does not work properly	Please ask professional maintenance or (back to the factory maintenance)

Electric Barbecue grills

Manual Book