

Instruction Manual

Please save this manual for future reference.

Product Name:	Reindeer and Sleigh Lighted Holiday Decoration

Thank you for purchasing this LuxenHöme product. This product has been manufactured with the highest standards of safety and quality.

PLEASE READ ALL INSTRUCTIONS BEFORE ASSEMBLY.

Unpack all parts from the packaging inside the carton to ensure there are no missing or damaged parts. Do not attempt to assemble or use the product if any parts are missing or damaged.

CARTON CONTENTS:

Description	Quantity
Reindeer Body	1
Reindeer Legs	4
Reindeer Head	1
Reindeer Antlers	2
Reindeer Tail	1
Sled Left Side	1
Sled Right Side	1
Sled Center	1
R-shaped bolt	16
Transformer	1
Stakes	8

Before You Start

1. Decide on an appropriate location for your product. Please read the assembly and Instruction procedure carefully.

Note: This decoration can be displayed outdoors and indoors.

2. Retain the instructions for future use and save the carton for storing your decoration.


Instruction Manual

Please save this manual for future reference.

Product Name:	Reindeer and Sleigh Lighted Holiday Decoration

Assembly and Instruction Procedure (no tools required for assembly):

1. Assemble the reindeer. See the image below. Be careful not to pinch any wires. Insert each of the four legs into the body of the reindeer. There are four metal positioning tubes. Insert the R pin hardware in the figure to prevent the legs from detaching from the body. Insert two latch rods into the deer's front and hind legs. Attach the deer's tail. Next, attach the deer head to the body as shown in the image below (follow the arrow direction). Attach the antlers to the deer's head.




Instruction Manual

Please save this manual for future reference.

Product Name:	Reindeer and Sleigh Lighted Holiday Decoration

- Next, assemble the sleigh taking care not to pinch any wires. See the image below. Attach the skis to the sled body sides left and right by inserting them into the tube and securing them with the R pins. Connect the body of the sled sides by lining up the tubes and secure with the R pins.




Instruction Manual

Please save this manual for future reference.

Product Name:	Reindeer and Sleigh Lighted Holiday Decoration

- When displaying outdoors, use the ground stakes to secure the display to the ground. Connect the wires for the lights to the plug (twist to tighten the connection).



Plug in the lights and enjoy the lighted decoration!



Warnings:

- Risk of Fire and Electric Shock – please follow instructions and warnings on lights.
- Keep wires clear of being pinched or cut during assembly or installation. Discard sets with cut or pinched insulation.
- This product is for decoration use only. Not to be used by children as a toy. Keep out of reach of small children.

Troubleshooting:

- Some bulbs are not lighting or do not come on: Search for any loose plug connections between the presents.
- Note: If this action does not resolve the issue, please contact customer service for assistance.