


Assembly Manual

Isaac Power Recliner with Power Headrest








CAUTION

THIS ASSEMBLY MANUAL CONTAINS IMPORTANT SAFETY INFORMATION.


PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Count parts before assembling.

A  1pc	B  1pc	C  1pc
Backrest	Seat	Left Wing
D  1pc	E  1pc	
Right Wing	Power Supply	


Step 1

Cut the plastic ties to remove the hardware pack (Includes: Power Supply (E)). Locate the Left Wing (C) and Right Wing (D) at the bottom of the Seat (B), then take them out.




Step 2

Zip up the Backrest (A) and the Seat (B) together.




Step 3

Slide the Backrest (A) into the metallic quick connectors of the Seat (B). Push down the Backrest (A) firmly until each side is locked into place and an audible “click” is heard.




Step 4

Connect the Headrest cable into the Headrest cable. Locate the Power Supply (E) and connect to its corresponding receiver on the base of the Seat (B).




Step 5

Slide the Left Wing (C) and Right Wing (D) into the Backrest (A).



Step 6

Attach the back cover to the bottom of the Seat (B) with Velcro.



Step 7

Plug the Power Supply (E) into the power outlet.

