







INSTALLATION & ASSEMBLY



MAINTENANCE AND WARNING

- 1.Keep furniture away from heat sources.
 - 2.Do not clean furniture with harsh cleaner or polishes.Do not use detergents,solvents,abrasives,spray packs or leather cleaner. Use non-color mild soa with warm water to clean spills(Mix 1:10 soap to water).
 - 3.Do not place furniture under direct sunlight,material will possibly fade over time.
 - 4.Do not use on site dry cleaning machine.Children should not climb or jump on the furniture.
 - 5.Do not write on furniture that is not protectedby a padded barrier.
 - 6.Not for commercial use,only for residential use.
-




INSTALLING THE CAM LOCKS

1




Do not over tighten!




The base of the Cam Screw should be flush with the panel

2




Screw the Cam Screw into the prethreaded hole. Tighten with a screwdriver until snug.

3




Connect the panels. Insert the Cam Screw into the small hole in the adjoining panel.

4




The head of the Cam Screw should be visible through the large hole.

5



Insert the Cam Lock into the hole. Make sure the arrow and the opening in the Cam Lock are facing the Cam Screw.


6















Do not over tighten!

Using a screwdriver, turn the Cam Lock at least 90° clock-wise to lock the two panels firmly together.











EXPLOSIVE VIEW



PARTS LIST


A	x1	B	x1	C	x1	D	x1
							
E	x1	F	x1	G	x1	H	x6
							
I	x1	J	x6	K	x2	L	x2
							


HARDWARE LIST


1	x12+1	2	x12+1	3	x6	4	x2	5	x20+1	6	x4
											
				ø8*30mm		ø4*25mm		ø3*14mm			
7	x4	8	x4	9	x4	10	x8	11	x48+2	12	x4
											
ø3*16mm				ø4*25mm				ø3.5*14mm			
13	x4	14	x2	15	x1						
											
ø3.5*35mm											

ASSEMBLY INSTRUCTIONS

STEP-1








4	x2
	
ø4*25mm	

15	x1
	

ASSEMBLY INSTRUCTIONS


STEP-2







1	x2	2	x2	3	x1	15	x1
							
				ø8*30mm			

ASSEMBLY INSTRUCTIONS


STEP-3





1	x4	2	x4	3	x2	15	x1
							
				ø8*30mm			


ASSEMBLY INSTRUCTIONS


STEP-4



1	x6
	


2	x6
	

3	x3
	
ø8*30mm	

15	x1
	


ASSEMBLY INSTRUCTIONS

STEP-5




ASSEMBLY INSTRUCTIONS

STEP-6




ASSEMBLY INSTRUCTIONS


STEP-7




ASSEMBLY INSTRUCTIONS


STEP-8



5	x20
	
ø3*14mm	


6	x2
	

7	x4
	
ø3*16mm	

15	x1
	

ASSEMBLY INSTRUCTIONS


STEP-9





8	x4	9	x4	10	x8	11	x16	15	x1
		ø4*25mm				ø3.5*14mm			

ASSEMBLY INSTRUCTIONS


STEP-10



11	x16	15	x1
			
ø3.5*14mm			







ASSEMBLY INSTRUCTIONS

STEP-11





ASSEMBLY INSTRUCTIONS

STEP-12




ASSEMBLY INSTRUCTIONS


STEP-13



1.Drill a hole in the wall with an electric drill.



2.Tap the plastic wall anchor into the hole with a hammer.



3.Secure the Anti-tip device ⑥ to the wall with screws ⑬.

6	x2

12	x4

13	x4
ø3.5*35mm	

15	x1

ASSEMBLY INSTRUCTIONS

STEP-14

WARNING

Children have died from furniture tipover.

To reduce the risk of furniture tipover:

- ALWAYS install Anti-tip device provided.
- For use with televisions weighing 35 lb or less. Use with heavier televisions may result in instability causing tip-over resulting in death or serious injury.
- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- NEVER open more than one drawer at a time.
- Place heaviest items in the lowest drawers.

