

Assembly Instructions

Outdoor TV Wood Cover
MDUS2-TC-WOOD



As this item contains many parts, please read the installation instruction carefully before installation. Please use tools properly and carefully.


PART LIST



1

Roof


1PCS



2

Base


1PCS



3

Left side panel


1PCS



4

Right side panel


1PCS



5

Large backboard


2PCS



6

Mezzanine


2PCS



7

Door panel ①


1PCS



8

Door panel ②


1PCS



9

Brace

1PCS




10

Brace

1PCS

PART LIST



⑪

Brace

1PCS



TV stand


1PCS



TV cloth cover

1PCS


HARDWARE LIST



4x35

A	26+5 PCS


Self tapping screws



4x25

B	24+5 PCS

Self tapping screws



3x16

C	18+4 PCS

Self tapping screws



8x30

D	38+9 PCS


Wooden sales



8x20


E	12+2 PCS

Wooden sales



F	3 PCS

Hinge



G	1 PCS

Shake hands




H	2 PCS

Handle screw




I	2 PCS

Air pressure rod



J	10+2 PCS


Rubber stopper



4x16

K	14+5 PCS


Self tapping screws



4x40

L	10+2 PCS


Self tapping screws



M	2 PCS


Thread hole cover

EXPLODED VIEW





INSTALLATION STEPS

STEP1




STEP2






INSTALLATION STEPS


STEP3





8x30	
D	20 PCS

STEP4







4x35	
A	26 PCS


INSTALLATION STEPS


STEP5






STEP6








INSTALLATION STEPS

STEP7









	 3x16	 4x25
F 3 PCS	C 9 PCS	B 24 PCS

STEP8







 3x16
C 9 PCS

INSTALLATION STEPS


STEP9







 4x16 K	14 PCS
 I	2 PCS
 G	1 PCS
 H	2 PCS

STEP10









 J	10 PCS

INSTALLATION STEPS

STEP11




	 4x40
Ⓜ 2 PCS	Ⓛ 10 PCS

INSTALLATION STEPS

STEP12

tools required





(M4X25)-4pcs



(M5X25)-4pcs



(M6X25)-4pcs



(M6)-4pcs



(φ15xφ8.2x10)-4pcs



(10mm)-1pcs



(7X80)-3pcs



(φ10xφ7x60)-3pcs




(M6x12)-4pcs

Note: The installation of the TV cabinet bracket can be found in the TV cabinet bracket manual


INSTALLATION STEPS

STEP13




Note: Drill wall holes according to the positioning of the TV cabinet bracket base Drill holes according to the TV bracket and TV hole position to position the installed TV in the middle of the TV cabinet


Note: The installation instructions for the TV stand are included in the TVstand box




(ϕ10xϕ7x60)-3pcs

STEP14







(7X80)-3pcs



(ϕ15xϕ8.2x10)-3pcs



(10mm)-1pcs

FLAT PATTERNMAKING

