

# ASSEMBLY & INSTALLATION INSTRUCTIONS

Please read carefully and save these instructions, as you may need them at a later date.

**IMPORTANT SAFETY INSTRUCTIONS:** This product has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.


## GENERAL

Remove the lamp and from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions.

## ASSEMBLY AND INSTALLATION

1. Fasten the Socket Assembly(2) onto the LAMP BASE(1).  
Be careful not to twist the power cord, tighten securely.
2. Place HARP( 3 ) onto the saddle(2).
3. Place the SHADE ( 4 ) onto HARP ( 3 ) and fix by tightening the FINIAL(5) onto the HARP(3).
4. Screw a light bulb into the lamp socket and make sure it does not exceed the maximum wattage specified on the lamp wattage rating label, **MAXIMUM 100 WATT**

**This 3-way socket is only suited for 3-way bulb, Please do not install normal single-filament bulb into this socket. Otherwise, it may cause short circuit or bulb exploded.**



1. LAMP BASE
2. NECK and SOCKET
3. HARP
4. SHADE
5. FINIAL