




Assembly Instruction












SKU:WF321414






Parts List





Parts List

①  X2	②  X2
③  X2	④  X2
⑤  X4	⑥  X16
⑦  X2	⑧  X1
⑨  X1	⑩  X3
⑪  X1	⑫  X1

Hardware



Ⓐ  M8×65mm X12	Ⓑ  M8×60mm X8	Ⓒ  M8×15mm X12	Ⓓ  M6×15mm X8
Ⓔ  M6×40mm X4	Ⓕ  M4 X1	Ⓖ  M5 X1	

1




	Ⓐ ×2
	Ⓔ ×1

2




	Ⓐ ×2
	Ⓔ ×1

3





4





	(D) x8
	(F) x1

5




	A × 4
	E × 2
	F × 1
	G × 1

6




	A × 4
	E × 2
	F × 1
	G × 1

7





	C x4
	G x1

8





	C x4
	G x1

9





	(B) x2
	(G) x1

10



	(C) x4
	(G) x1

11



	Ⓑ × 6
	Ⓒ × 1

12

